



i50

DEPTH / SPEED / TRIDATA INSTRUMENTS

INSTALLATION & OPERATION INSTRUCTIONS

English (en-US)
Date: 10-2024
Document number: 81341 (Rev 6)
© 2024 Raymarine UK Limited

Raymarine®

Legal notices

Trademark and patents notice

Raymarine, Tacktick, Pathfinder, ClearPulse, Truzoom, SeaTalk, SeaTalk^{hs}, SeaTalkng, and **Micronet**, are registered or claimed trademarks of Raymarine Belgium.

FLIR, Fishidy, Fishing Hot Spots, YachtSense, DockSense, LightHouse, RangeFusion, DownVision, SideVision, RealVision, HyperVision, Dragonfly, Element, Quantum, Axiom, Instalert, Infrared Everywhere, The World's Sixth Sense and **ClearCruise** are registered or claimed trademarks of FLIR Systems, Inc.

All other trademarks, trade names, or company names referenced herein are used for identification only and are the property of their respective owners.

This product is protected by patents, design patents, patents pending, or design patents pending.

Fair Use Statement

You may print no more than three copies of this manual for your own use. You may not make any further copies or distribute or use the manual in any other way including without limitation exploiting the manual commercially or giving or selling copies to third parties.

Content notice

Please ensure that you have obtained this document only from Raymarine®, and that it is the **latest** available version.

There are numerous third-party Internet websites (such as *www.manualslib.com*) hosting Raymarine product manuals. These websites are not authorized by Raymarine® to do so, and are often hosting illegitimate or older versions of Raymarine product manuals, which may contain inaccurate or misleading information.

To obtain the latest official documentation for a Raymarine® product, please visit the official Raymarine® website: <https://bit.ly/rym-docs>

Artificial Intelligence (AI) content notice

There are numerous third-party **Artificial Intelligence (AI)** services available to the public, which are capable of providing a summary or transcription of the information provided by official Raymarine® publications or websites, either in written or audio/video formats. These services may alter, supplement, or convey the original information provided by Raymarine® in inaccurate or misleading ways.

Please ensure that you have obtained this document only from Raymarine®, and that it is the **latest** available version.

CONTENTS

CHAPTER 1 IMPORTANT INFORMATION.....	10		
Safety warnings	10		
Product warnings	10		
Regulatory notices.....	11		
Water ingress	11		
Disclaimer.....	11		
EMC installation guidelines.....	11		
Suppression ferrites.....	12		
Connections to other equipment.....	12		
Compass safe distance	12		
Declaration of conformity.....	12		
IMO and SOLAS	12		
Warranty registration	12		
Product disposal	13		
Technical accuracy.....	13		
Publication copyright	13		
CHAPTER 2 DOCUMENT INFORMATION.....	14		
2.1 Applicable products.....	15		
2.2 Product documentation	15		
Printed (hardcopy) product manuals	15		
2.3 Document illustrations	16		
2.4 Applicable software version	16		
CHAPTER 3 PRODUCT AND SYSTEM OVERVIEW	17		
3.1 Product overview	18		
3.2 Compatible transducers	18		
Instrument Depth transducers	18		
Instrument Speed and Temperature transducers	18		
Instrument Depth, Speed and Temperature (DST) transducers	19		
3.3 System protocols and cable systems	19		
SeaTalk NG.....	20		
NMEA 2000	20		
SeaTalk 1.....	20		
CHAPTER 4 PARTS SUPPLIED	21		
4.1 Parts supplied.....	22		
4.2 Inline fuse requirement.....	22		
CHAPTER 5 PRODUCT DIMENSIONS	23		
5.1 Product dimensions	24		
CHAPTER 6 LOCATION REQUIREMENTS	25		
6.1 Warnings and cautions.....	26		
6.2 General location requirements	26		
6.3 EMC installation guidelines	26		
6.4 Compass safe distance.....	27		
6.5 Viewing angle considerations	27		
6.6 General speed and depth transducer location requirements.....	27		
6.7 Speed and depth transducer mounting	28		
CHAPTER 7 MOUNTING.....	29		

7.1 Tools required	30	10.1 Power options.....	45
7.2 Removing the front bezel.....	30	10.2 SeaTalk NG power connection.....	45
7.3 Mounting	30	10.3 SeaTalk NG power supply	46
CHAPTER 8 CABLES AND CONNECTIONS —		10.4 Inline fuse requirement.....	46
GENERAL INFORMATION	32	10.5 Inline fuse and thermal breaker ratings.....	46
8.1 General cabling guidance.....	33	10.6 SeaTalk NG power cables	47
Cable types and length	33	10.7 SeaTalk NG product loading	47
Cable routing	33	10.8 SeaTalk NG power connection point.....	48
Strain relief.....	33	10.9 SeaTalk NG system loading.....	48
Cable shielding	33	10.10 Power distribution — SeaTalk NG	49
Suppression ferrites.....	33	10.11 Power connection via Autopilot Control Unit (ACU-Series)	51
Connecting cables.....	34	CHAPTER 11 POWER CONNECTIONS (SEATALK	
Bare-ended wire connections.....	34	1 CONNECTIONS).....	52
8.2 Connections overview	34	11.1 Power options	53
Replacing spade terminals.....	35	11.2 SeaTalk 1 power connection	53
CHAPTER 9 NETWORK CONNECTIONS	36	11.3 Inline fuse requirement.....	54
9.1 Transducer connection options	37	11.4 Inline fuse and thermal breaker ratings.....	54
Direct transducer connections.....	37	CHAPTER 12 POWER CONNECTIONS (DIRECT	
iTC-5 transducer connections	39	CONNECTIONS).....	55
Transducer pod connections	40	12.1 Power options.....	56
9.2 SeaTalk 1 connection	40	12.2 Direct power connection	56
9.3 SeaTalk NG connection	41	12.3 Inline fuse requirement.....	57
Connecting SeaTalk NG cables	42	12.4 Inline fuse and thermal breaker ratings.....	57
9.4 NMEA 2000 network connection	43	12.5 Power distribution	57
CHAPTER 10 POWER CONNECTIONS (SEATALK		12.6 Power cable extension (12 / 24 V systems).....	60
NG CONNECTIONS)	44	CHAPTER 13 i50 DEPTH	61
		13.1 i50 Depth operation.....	62

13.2 i50 Depth controls	62	Enabling / Disabling alarms	70
13.3 Switching on the display	63	Setting alarm thresholds — i50 Depth	70
13.4 Switching off the display	63	Shallow alarm lock	70
13.5 Data master	63	13.10 Illumination	71
Changing i50 Depth Master / Repeater		Adjusting the backlight level	71
status	63	Adjusting the contrast.....	71
13.6 Calibration	64	Group illumination	71
Depth calibration pages.....	64	Assigning the i50 Depth to a group.....	71
Selecting the unit of measure for depth			
readings	64		
Depth Offset.....	65		
Applying a Depth Offset.....	65		
Checking the software version.....	66		
Locking access to the User Calibration			
menu.....	66		
Setting the response delay for depth			
readings	66		
Enabling and disabling Boat Show Mode.....	67		
Resetting the display to factory default			
settings.....	67		
13.7 Using the depth pages	68		
13.8 Viewing the depth offset.....	68		
13.9 Alarms	69		
Instrument alarms.....	69		
Alarm indications	69		
Silencing alarms	70		
		CHAPTER 14 I50 SPEED	73
		14.1 i50 Speed operation.....	74
		14.2 i50 Speed controls.....	74
		14.3 Switching on the display	75
		14.4 Switching off the display	75
		14.5 Calibration	75
		Speed calibration pages	75
		Selecting the unit of measure for speed	
		readings	75
		Changing speed resolution	76
		Selecting the unit of measure for log	
		readings	76
		1 Point speed calibration	77
		Nautical measured mile markers	78
		Selecting unit of measure for water	
		temperature readings	79
		Calibrating water temperature.....	79
		Enabling and disabling the timer buzzers.....	80

Checking i50 Speed Software Version and Master / Repeater status	81	15.5 Data master	92
Performing a Speed Run Calibration.....	81	Changing i50 Tridata Master / Repeater status	93
Locking access to the User Calibration menu.....	83	15.6 Calibration	93
Setting the response delay for speed readings	83	Tridata calibration pages	93
Setting the response delay for Velocity Made Good (VMG) readings	84	Selecting the unit of measure for depth readings	94
Enabling and disabling Boat Show Mode.....	85	Depth Offset.....	94
Resetting the display to factory defaults.....	85	Applying a Depth Offset.....	95
14.6 Using the speed pages	86	Selecting the unit of measure for speed readings	95
14.7 Using the log, trip and temperature pages.....	87	Selecting a resolution for speed readings	96
14.8 Using the timers	87	Selecting the unit of measure for log readings	96
Setting the race start timer	88	1 point speed calibration.....	97
Timer buzzer.....	88	Nautical measured mile markers.....	98
14.9 Illumination	88	Selecting unit of measure for water temperature readings	99
Adjusting the backlight level	88	Calibrating water temperature.....	100
Adjusting the contrast.....	88	Enabling and disabling timer buzzers.....	100
Group illumination	88	Checking the software version.....	101
CHAPTER 15 I50 TRIDATA	90	Performing Speed Run Calibration	101
15.1 i50 Tridata operation	91	Locking access to the User Calibration menu.....	103
i50 Tridata display layout.....	91	Setting speed to SOG	103
15.2 i50 Tridata controls.....	92		
15.3 Switching on the display	92		
15.4 Switching off the display	92		

Setting the response delay for speed readings	104	16.3 Cleaning the display case	114
Setting the response delay for depth readings	105	16.4 Cleaning the display screen.....	114
Enabling and disabling Boat Show Mode.....	105	CHAPTER 17 TROUBLESHOOTING	115
Resetting the display to factory defaults.....	106	17.1 Troubleshooting	116
15.7 Using Tridata depth pages	107	17.2 Instrument troubleshooting.....	116
15.8 Using Tridata speed pages	107	17.3 Power up troubleshooting.....	117
15.9 Using Tridata trip, log, temp and timer pages.....	108	17.4 Miscellaneous troubleshooting.....	118
15.10 Using the timers	109	CHAPTER 18 TECHNICAL SUPPORT.....	119
Setting the race timer	109	18.1 Raymarine technical support and servicing.....	120
Timer buzzer.....	109	18.2 Checking the software version	121
15.11 Alarms.....	109	18.3 Learning resources	121
Instrument alarms.....	109	CHAPTER 19 TECHNICAL SPECIFICATION.....	122
Alarm indications	110	19.1 Physical specification	123
Silencing alarms	110	19.2 Power specification	123
Enabling / Disabling alarms	110	19.3 Network specification.....	123
Setting alarm thresholds.....	111	19.4 Environmental specification	123
Shallow alarm lock	111	19.5 Display specification	123
15.12 Illumination	111	19.6 Conformance specification.....	123
Adjusting the backlight level	111	CHAPTER 20 SPARES AND ACCESSORIES	124
Adjusting the contrast.....	111	20.1 Spares.....	125
Group illumination	111	20.2 Accessories.....	125
CHAPTER 16 MAINTAINING YOUR DISPLAY.....	113	20.3 SeaTalk NG cables and accessories	125
16.1 Service and maintenance	114	APPENDIX A NMEA 2000 PGNS	131
16.2 Routine equipment checks.....	114	APPENDIX B SOFTWARE RELEASE HISTORY	132

CHAPTER 1: IMPORTANT INFORMATION

Safety warnings



Warning: Product installation and operation

- This product must be installed and operated in accordance with the instructions provided. Failure to do so could result in personal injury or damage to your vessel. It may also cause poor product performance or invalidate the product warranty.
- Raymarine highly recommends certified installation by a Raymarine approved installer. A certified installation qualifies for enhanced product warranty benefits. Register your warranty on the Raymarine website: www.raymarine.com/warranty



Warning: Potential ignition source

This product is NOT approved for use in hazardous/flammable atmospheres. Do NOT install in a hazardous/flammable atmosphere (such as in an engine room or near fuel tanks).



Warning: High voltage

This product contains high voltage. Adjustments require specialized service procedures and tools only available to qualified service technicians. There are no user serviceable parts or adjustments. The operator should never remove the cover or attempt to service the product.



Warning: Switch off power supply

Ensure the vessel's power supply is switched OFF before starting to install this product. Do NOT connect or disconnect equipment with the power switched on, unless instructed in this document.

Product warnings

Caution: Power supply protection

When installing this product ensure the power source is adequately protected by means of a suitably-rated fuse or thermal circuit breaker.



Warning: Positive ground systems

Do not connect this unit to a system which has positive grounding.

Caution: Service and maintenance

This product contains no user serviceable components. Please refer all maintenance and repair to authorized Raymarine dealers. Unauthorized repair may affect your warranty.

Caution: Transducer cable

- Do NOT use the transducer cable to lift or suspend the transducer; always support the transducer body directly during installation.
- Do NOT cut, shorten, or splice the transducer cable.
- Do NOT remove the connector.

If the cable is cut, it cannot be repaired. Cutting the cable will also void the warranty.

Caution: Sun covers

- If your product is supplied with a sun cover, to protect against the damaging effects of ultraviolet (UV) light, always fit the sun cover when the product is not in use.
- To avoid potential loss, sun covers must be removed when travelling at high speed, whether in water or when the vessel is being towed.

Caution: Product cleaning

When cleaning products:

- Switch off power supply.
- Use a clean damp cloth to wipe clean.
- Do NOT use: abrasive, acidic, ammonia, solvent or other chemical based cleaning products.
- Do NOT use a jet wash.

Caution: Condensation

Certain atmospheric conditions may cause a small amount of condensation to form on the unit's window. This will not damage the unit and will clear after the unit has been switched on for a short period.

Regulatory notices

Water ingress

Water ingress disclaimer

Although the waterproof rating capacity of this product meets the stated water ingress protection standard (refer to the product's *Technical Specification*), water intrusion and subsequent equipment failure may occur if the product is not installed correctly or subjected to high-pressure washing. Raymarine will not warrant products subjected to high-pressure washing.

Disclaimer

Raymarine does not warrant that this product is error-free or that it is compatible with products manufactured by any person or entity other than Raymarine.

Raymarine is not responsible for damages or injuries caused by your use or inability to use the product, by the interaction of the product with products manufactured by others, or by errors in information utilized by the product supplied by third parties.

Third-party hardware, such as converters, adapters, routers, switches, Access Points etc., provided by third parties, may be made available directly to you by other companies or individuals under separate terms and conditions, including separate fees and charges. Raymarine UK Ltd or its affiliates have not tested or screened the third-party hardware.

Raymarine has no control over, and is not responsible for:

- (a) the content and operation of such third-party hardware; or
- (b) the privacy or other practices of such third-party hardware.

The fact that Raymarine's documentation may make reference to such third-party hardware does not indicate any approval or endorsement of any such third-party hardware. Raymarine may reference such third-party hardware only as a convenience.

THIS INFORMATION IS MADE AVAILABLE BY Raymarine ON THE BASIS THAT YOU EXCLUDE TO THE FULLEST EXTENT LAWFULLY PERMITTED ALL LIABILITY WHATSOEVER FOR ANY LOSS OR DAMAGE HOWSOEVER ARISING OUT OF THE USE OF THIS INFORMATION OR RELIANCE UPON THIS INFORMATION.

Raymarine does not exclude Raymarine's liability (if any) to you for personal injury or death resulting from Raymarine UK Ltd negligence, for fraud or for any matter which it would be illegal to exclude or to attempt to exclude.

EMC installation guidelines

Raymarine equipment and accessories conform to the appropriate Electromagnetic Compatibility (EMC) regulations, to minimize electromagnetic interference between equipment and minimize the effect such interference could have on the performance of your system.

Correct installation is required to ensure that EMC performance is not compromised.

Note:

In areas of extreme EMC interference, some slight interference may be noticed on the product. Where this occurs the product and the source of the interference should be separated by a greater distance.

For **optimum** EMC performance we recommend that wherever possible:

- Raymarine equipment and cables connected to it are:
 - At least 1 m (3.28 ft) from any equipment transmitting or cables carrying radio signals e.g. VHF radios, cables and antennas. In the case of SSB radios, the distance should be increased to 2 m (6.6 ft).
 - More than 2 m (6.56 ft) from the path of a Radar beam. A Radar beam can normally be assumed to spread 20 degrees above and below the radiating element.
- The product is supplied from a separate battery from that used for engine start. This is important to prevent erratic behavior and data loss which can occur if the engine start does not have a separate battery.
- Raymarine specified cables are used.
- Cables are not cut or extended, unless doing so is detailed in the installation manual.

Note:

Where constraints on the installation prevent any of the above recommendations, always ensure the maximum possible separation between different items of electrical equipment, to provide the best conditions for EMC performance throughout the installation.

Suppression ferrites

- Raymarine cables may be pre-fitted or supplied with suppression ferrites. These are important for correct EMC performance. If ferrites are supplied separately to the cables (i.e. not pre-fitted), you must fit the supplied ferrites, using the supplied instructions.
- If a ferrite has to be removed for any purpose (e.g. installation or maintenance), it must be replaced in the original position before the product is used.
- Use only ferrites of the correct type, supplied by Raymarine or its authorized dealers.
- Where an installation requires multiple ferrites to be added to a cable, additional cable clips should be used to prevent stress on the connectors due to the extra weight of the cable.

Connections to other equipment

Requirement for ferrites on non-Raymarine cables:

If your Raymarine equipment is to be connected to other equipment using a cable not supplied by Raymarine, a suppression ferrite **MUST** always be attached to the cable near the Raymarine unit.

For more information, refer to your third-party cable manufacturer.

Compass safe distance

To prevent potential interference with the vessel's magnetic compasses, ensure an adequate distance is maintained from the product.

When choosing a suitable location for the product you must aim to maintain a distance of at least 1 m (3.3 ft) in all directions from any compasses.

For some smaller vessels it may not be possible to locate the product this far away from a compass. In this situation, when choosing the installation location for your product, ensure that the compass is not affected by the product when it is in a powered on state.

Declaration of conformity

Raymarine UK Ltd declares that this product is compliant with the essential requirements of EMC Directive 2014/30/EU.

The original Declaration of Conformity certificate may be viewed on the relevant product page at: <https://bit.ly/rym-docs>

IMO and SOLAS

The equipment described within this document is intended for use on leisure marine boats and workboats NOT covered by International Maritime Organization (IMO) and Safety of Life at Sea (SOLAS) Carriage Regulations.

Warranty registration


To register your Raymarine product ownership, please visit <https://bit.ly/rym-warranty> and register online.

It is important that you register your product to receive full warranty benefits. Your unit package includes a bar code label indicating the serial number of the unit. You will need this serial number when registering your product online. You should retain the label for future reference.

Product disposal

Dispose of this product in accordance with the WEEE Directive.

The Waste Electrical and Electronic Equipment (WEEE) Directive requires the recycling of waste electrical and electronic equipment which contains materials, components and substances that may be hazardous and present a risk to human health and the environment when WEEE is not handled correctly.



Equipment marked with the crossed-out wheeled bin symbol indicates that the equipment should not be disposed of in unsorted household waste. Local authorities in many regions have established collection schemes under which residents can dispose of waste electrical and electronic equipment at a recycling center or other collection point. For more information about suitable collection points for waste electrical and electronic equipment in your region, refer to the Raymarine website: <https://bit.ly/rym-recycling>

Technical accuracy

To the best of our knowledge, the information in this document was correct at the time it was produced. However, Raymarine cannot accept liability for any inaccuracies or omissions it may contain. In addition, our policy of continuous product improvement may change specifications without notice. As a result, Raymarine cannot accept liability for any differences between the product and this document. Please check the Raymarine website (<https://bit.ly/raymarine-home>) to ensure you have the most up-to-date version(s) of the documentation for your product.

Publication copyright

Copyright ©2024 Raymarine UK Ltd. All rights reserved. No parts of this material may be copied, translated, or transmitted (in any medium) without the prior written permission of Raymarine UK Ltd.

CHAPTER 2: DOCUMENT INFORMATION

CHAPTER CONTENTS

- 2.1 Applicable products — page 15
- 2.2 Product documentation — page 15
- 2.3 Document illustrations — page 16
- 2.4 Applicable software version — page 16

2.1 Applicable products

This document is applicable to the following products:

Part number	Description
E70059	<u>i50 Depth</u> , includes: <ul style="list-style-type: none">i50 Depth SeaTalk NG instrument display.
E70148	<u>i50 Depth Thru-hull system pack</u> , includes: <ul style="list-style-type: none">i50 Depth SeaTalk NG instrument display.P319 Thru-hull Depth transducer.
E70058	<u>i50 Speed</u> , includes: <ul style="list-style-type: none">i50 Speed SeaTalk NG instrument display.
E70147	<u>i50 Speed Thru-hull system pack</u> , includes: <ul style="list-style-type: none">i50 Speed SeaTalk NG instrument display.P120 Thru-hull Speed and Temp transducer
E70060	<u>i50 Tridata</u> , includes: <ul style="list-style-type: none">i50 Tridata SeaTalk NG instrument display.
E70149	<u>i50 Tridata Thru-hull system pack</u> , includes: <ul style="list-style-type: none">i50 Tridata SeaTalk NG instrument display.P319 Thru-hull Depth transducer.P120 Thru-hull Speed and Temp transducer.
E70153	<u>i50 & i60 Depth, Speed & Wind system pack</u> , includes: <ul style="list-style-type: none">i50 Depth SeaTalk NG instrument display.P319 Thru-hull Depth transducer.i50 Speed SeaTalk NG instrument display.P120 Thru-hull Speed and Temp transduceri60 Wind SeaTalk NGShort-Arm Masthead Wind vane transducer

2.2 Product documentation

The following documentation is applicable to your product:

Applicable documents

Document	Description	Link
81341	i50 Installation and Operation Instructions (this document).	www.bit.ly/i50-docs
87130	i50 Mounting template.	www.bit.ly/i50-docs

Related documentation

Document	Description	Link
87221	Rotavecta Installation Instructions.	www.bit.ly/rotavecta-docs
87220	Short-Arm & Long-Arm Masthead Wind Vane Installation Instructions.	www.bit.ly/rym-wind-docs
—	Depth and Speed Transducer Installation Instructions.	<i>As supplied with your transducer</i>

Printed (hardcopy) product manuals

Raymarine provides a Print Shop service, enabling you to purchase a high-quality, professionally-printed manual for your Raymarine product, delivered directly to your door.

Printed manuals are ideal for keeping onboard your vessel, as a useful source of reference whenever you need assistance with your Raymarine product.

Printed manuals are provided by a third-party (**Lulu Press**).

To order a printed manual, use the Lulu Press website link provided below. The manual will then be printed and delivered to the address you specify. Once an order is placed, it typically takes Lulu Press approximately 5 to 10 working days to print and deliver a printed manual.

Supplier	Book purchase link
	www.bit.ly/rym-i50-book

Note:

- Accepted methods of payment for printed manuals are credit cards and PayPal.
- Printed manuals can be shipped worldwide.
- Further manuals will be added to the Print Shop over the coming months for both new and legacy products.
- Raymarine user manuals are also available to download free-of-charge from the Raymarine website, in the popular PDF format. These PDF files can be viewed on a PC / laptop, tablet, smartphone, or on the latest generation of Raymarine multifunction displays.

2.3 Document illustrations

Your product and if applicable, its user interface may differ slightly from that shown in the illustrations in this document, depending on product variant and date of manufacture.

All images are provided for illustration purposes only.

2.4 Applicable software version

Product software is updated regularly to add new features and improve existing functionality.

This document has been updated to reflect the following i50 software version:

Applicable software version:

v1.06

Check the website for the latest software:

software download link

www.bit.ly/i50-download


CHAPTER 3: PRODUCT AND SYSTEM OVERVIEW

CHAPTER CONTENTS

- 3.1 Product overview — page 18
- 3.2 Compatible transducers — page 18
- 3.3 System protocols and cable systems — page 19

3.1 Product overview

The i50 range of SeaTalk NG instrument displays can be connected directly to the relevant transducers. The data can be transmitted on the SeaTalk NG network to other compatible displays.



1. i50 Depth.
2. i50 Speed.
3. i50 Tridata.

The i50 instrument display range offers the following features:

- Integrates with Raymarine autopilots and navigation equipment on the SeaTalk NG network.
- Surface mountable.
- Extra large (28 mm max) digits.
- Provides good visibility in all lighting conditions.
- Low power consumption.


3.2 Compatible transducers

Instrument Depth transducers

The depth transducers listed below are compatible with the following instrument displays:

- i40 Depth / i40 Bidata.
- i50 Depth / i50 Tridata.

- i70 / i70s via iTC-5 converter.




Part number	Transducer description
E26009	P7 Thru-hull
E26019-PZ	B45 (including fairing block) Thru-hull
M78717	B17 Thru-hull
M78713-PZ	P319 Thru-hull
E26030	P17 Thru-hull
E26001-PZ	P79 In-hull
A80373	P79S In-hull
— T70278	— (includes SeaTalk NG adaptor)
E26027-PZ	P66 Transom mount

Instrument Speed and Temperature transducers

The speed and temperature transducers listed below are compatible with the following instrument displays:

- i40 Speed / i40 Bidata.
- i50 Speed / i50 Tridata.
- i70 / i70s via iTC-5 converter.



Part number	Description
E25025	P17 Thru-hull
E26031	ST800 -P120 Thru-hull.
E70673	ST900 -P120 Thru-hull, with 13.7 m (44.95 ft) fitted cable.
E70674	ST900 -P120 Thru-hull, with 20 m (65.62 ft) fitted cable.
E66072	ST800 -B120 Thru-hull.
E70686	ST900 -B120 Thru-hull, with 13.7 m (44.95 ft) fitted cable.
E70687	ST950 -P17 Thru-hull with 6 m (19.69 ft) fitted cable.
E26008	P371 Thru-hull.
E26005	ST69 Transom mount.


Instrument Depth, Speed and Temperature (DST) transducers

The DST transducers listed below are compatible with the following instrument displays:

- i40 Depth / i40 Speed / i40 Bidata.

[Product and system overview](#)

- i50 Depth / i50 Speed / i50 Tridata.
- i70 / i70s via iTC-5 converter.



Part number	Transducer description
A22154	DST-800 Thru-hull
E26028-PZ	P66 Transom mount
E26006-PZ	P65 / ST40 Transom mount
A26043	B744V (including fairing block) Thru-hull
A26044	B744VL (including fairing block) Thru-hull

3.3 System protocols and cable systems

Your product can be connected to various products and systems to share information and so improve the functionality of the overall system.

These connections may be made using a number of different protocols and cable systems. Fast and accurate data collection and transfer is achieved by using a combination of the following data protocols and cable systems:

- SeaTalk 1
- SeaTalk NG

- NMEA 2000

Note:

You may find that your system does not use all of the connection types or instrumentation described in this section.

SeaTalk NG

SeaTalk NG (*Next Generation*) is an enhanced cable system for the connection of compatible marine instruments and equipment. It replaces the older SeaTalk 1 and SeaTalk 2 cable systems.

SeaTalk NG utilizes a single backbone which compatible equipment connects to using a spur. Data and power are carried within the backbone. Devices that have a low power draw can be powered from the network, although high current equipment will need to have a separate power connection.

SeaTalk NG is a proprietary extension to NMEA 2000 and the proven CAN bus technology. Compatible NMEA 2000, SeaTalk 1 and SeaTalk 2 devices can also be connected using the appropriate interfaces or adaptor cables as required.

NMEA 2000

The NMEA 2000 Data Interface Standard was developed by the NMEA® (*National Marine Electronics Association of America*). It is an international standard to enable equipment from many different manufacturers to be connected together and share information.

The NMEA 2000 standard was specifically intended to allow for a whole network of marine electronics from any manufacturer to communicate on a common bus via standardized message types and formats.

NMEA 2000 offers significant improvements over NMEA 0183, most notably in speed and connectivity. Up to 50 units can simultaneously transmit and receive on a single physical bus at any one time, with each node being physically addressable.

This disciplined multiple-talker, multiple-listener data network is therefore a significant improvement when compared to the NMEA 0183 single-talker, multiple-listener (simplex) serial communications protocol.

NMEA 2000 utilizes a single backbone which compatible equipment connects to using a spur. Data and power are carried within the backbone. Devices that have a low power draw can be powered from the network, although high current equipment will need to have a separate power connection.

DeviceNet

Electrically, NMEA 2000 is very similar to, and compatible with, the *Controller Area Network* ("CAN bus") technology known as "DeviceNet". Specifically, at the protocol higher-level, NMEA 2000 is based on *Society of Automotive Engineers* (SAE) J1939, with specific messages for the marine environment. Due to their electrical compatibility, NMEA 2000 devices and DeviceNet devices can co-exist on the same physical network, and can also use the same cables. Typically, the DeviceNet cables used in NMEA 2000 networks are known as "*Micro-C*", or sometimes just "*Micro*".

SeaTalk 1

SeaTalk 1 is a cable system which enables compatible devices (typically, instruments) to connect to each other and share data.

SeaTalk 1 is used to connect compatible instruments and equipment. A single SeaTalk 1 cable carries both power and data signals, and enables the connection of multiple devices without the need for a central processor or gateway.

Additional instruments and functions can be added to a SeaTalk 1 system, simply by plugging them into the network. SeaTalk 1 equipment can also communicate with other non-SeaTalk 1 equipment via the NMEA 0183 standard, provided a suitable interface / converter is used. SeaTalk 1 devices can also be connected to SeaTalk NG systems, via adapter cables and the SeaTalk 1 to SeaTalk NG converter (E22158).


CHAPTER 4: PARTS SUPPLIED

CHAPTER CONTENTS

- [4.1 Parts supplied — page 22](#)
- [4.2 Inline fuse requirement — page 22](#)

4.1 Parts supplied

The following parts are supplied in the box.



Description


- | | |
|-----------|--|
| 1 | 1x Instrument display. |
| 2 | 1x Suncover (to match i70s, p70s, p70Rs and eS Series). |
| 3 | 1x Suncover (to match a, c and e Series). |
| 4 | 1x Documentation pack. |
| 5 | 1x Gasket. |
| 6 | 1x Front bezel (to match i70s, p70s, p70Rs and eS Series). |
| 7 | 1x Front bezel (to match a, c and e Series). |
| 8 | 4x Fixing screws. |
| 9 | 1x SeaTalk NG blanking plug. |
| 10 | 1x SeaTalk NG spur cable, 400 mm (15.7 in). |

4.2 Inline fuse requirement

If your product is NOT supplied with an inline fuse (whether separately or fitted to the power cable), you **MUST** fit a suitably-rated inline fuse to your product's red power wire, housed in a waterproof fuse holder.

The illustration below shows the two main types of inline fuse with waterproof holder, for use in marine electronics installations. Fuses in a variety of ratings are widely available at chandleries and marine electrical retailers.

Select one of the following fuse types to protect your Raymarine product:



1. Waterproof fuse holder containing a "glass"-type inline fuse.
2. Waterproof fuse holder containing a "blade"-type inline fuse.

Fuse ratings:


- *Voltage rating* — must be equal to or greater than the voltage of your vessel's power supply.
- *Current rating* — refer to the *Inline fuse and thermal breaker rating* section in this document.

CHAPTER 5: PRODUCT DIMENSIONS

CHAPTER CONTENTS

- [5.1 Product dimensions — page 24](#)

5.1 Product dimensions



Description

A	110.00 mm (4.33 in).
B	115.00 mm (4.53 in).
C	14.00 mm (0.55 in).
D	30.00 mm (1.18 in).
E	35.00 mm (1.38 in).
F	90.00 mm (3.54 in).
G	17.00 mm (0.67 in).

CHAPTER 6: LOCATION REQUIREMENTS

CHAPTER CONTENTS

- 6.1 Warnings and cautions — page 26
- 6.2 General location requirements — page 26
- 6.3 EMC installation guidelines — page 26
- 6.4 Compass safe distance — page 27
- 6.5 Viewing angle considerations — page 27
- 6.6 General speed and depth transducer location requirements — page 27
- 6.7 Speed and depth transducer mounting — page 28

6.1 Warnings and cautions

Important:

Before proceeding, ensure that you have read and understood the warnings and cautions provided in the following section of this document:

[p.10 — Important information](#)



Warning: Potential ignition source

This product is NOT approved for use in hazardous/flammable atmospheres. Do NOT install in a hazardous/flammable atmosphere (such as in an engine room or near fuel tanks).

6.2 General location requirements

When selecting a location for your product it is important to consider a number of factors.

Factors for consideration:

- **Ventilation** — To ensure adequate airflow:
 - Ensure that product is mounted in a compartment of suitable size.
 - Ensure that ventilation holes are not obstructed. Allow adequate separation of all equipment.
- Any specific requirements for each system component are provided later in this chapter.
- **Mounting surface** — Ensure product is adequately supported on a secure surface. Do not mount units or cut holes in places which may damage the structure of the vessel.
- **Cabling** — Ensure the product is mounted in a location which allows proper routing, support and connection of cables:
 - Minimum bend radius of 100 mm (3.94 in) unless otherwise stated.
 - Use cable clips to prevent stress on connectors.
 - If your installation requires multiple ferrites to be added to a cable then additional cable clips should be used to ensure the extra weight of the cable is supported.

- **Water ingress** — The product is suitable for mounting both above and below decks. Although the unit is waterproof, it is good practice to locate it in a protected area away from prolonged and direct exposure to rain and salt spray.
- **Electrical interference** — Select a location that is far enough away from devices that may cause interference, such as motors, generators and radio transmitters / receivers.
- **Power supply** — Select a location that is as close as possible to the vessel's DC power source. This will help to keep cable runs to a minimum.

6.3 EMC installation guidelines

Raymarine equipment and accessories conform to the appropriate Electromagnetic Compatibility (EMC) regulations, to minimize electromagnetic interference between equipment and minimize the effect such interference could have on the performance of your system.

Correct installation is required to ensure that EMC performance is not compromised.

Note:

In areas of extreme EMC interference, some slight interference may be noticed on the product. Where this occurs the product and the source of the interference should be separated by a greater distance.

For **optimum** EMC performance we recommend that wherever possible:

- Raymarine equipment and cables connected to it are:
 - At least 1 m (3.28 ft) from any equipment transmitting or cables carrying radio signals e.g. VHF radios, cables and antennas. In the case of SSB radios, the distance should be increased to 2 m (6.6 ft).
 - More than 2 m (6.56 ft) from the path of a Radar beam. A Radar beam can normally be assumed to spread 20 degrees above and below the radiating element.
- The product is supplied from a separate battery from that used for engine start. This is important to prevent erratic behavior and data loss which can occur if the engine start does not have a separate battery.

- Raymarine specified cables are used.
- Cables are not cut or extended, unless doing so is detailed in the installation manual.

Note:

Where constraints on the installation prevent any of the above recommendations, always ensure the maximum possible separation between different items of electrical equipment, to provide the best conditions for EMC performance throughout the installation.

6.4 Compass safe distance

To prevent potential interference with the vessel's magnetic compasses, ensure an adequate distance is maintained from the product.

When choosing a suitable location for the product you must aim to maintain a distance of at least 1 m (3.3 ft) in all directions from any compasses.

For some smaller vessels it may not be possible to locate the product this far away from a compass. In this situation, when choosing the installation location for your product, ensure that the compass is not affected by the product when it is in a powered on state.

6.5 Viewing angle considerations

As display contrast and color are affected by the viewing angle, It is recommended that you temporarily power up the display, prior to installation, to enable you to best judge which location provides the optimum viewing angle.


For viewing angles for your product refer to the *Technical specification*.

6.6 General speed and depth transducer location requirements

When selecting a location for your transducer it is important to consider a number of factors.

The transducer should be mounted in a clear water flow area, as indicated by the key shown in the following image.

[Location requirements](#)



Description


- | | |
|----------|---------------------------|
| 1 | Sailing vessel |
| 2 | Planing power vessel |
| 3 | Displacement power vessel |

Each transducer should also:

- Be ahead of the propellers (by a minimum of 10% of the water line length).
- Be at least 150 mm (5.91 in) away from the keel (ideally ahead of the keel on a sailing yacht).
- Be as near as possible to the center line of the vessel.
- Be clear of other through-hull fittings or projections.
- Have sufficient clearance inside the hull to fit the nut.
- Have 100 mm (3.94 in) of headroom to allow for withdrawal.

Note:

In addition to the requirements listed above, the depth transducer must also be mounted within 10° of the vertical.



6.7 Speed and depth transducer mounting

Ensure transducers are installed in accordance with the instructions supplied with the transducer.


CHAPTER 7: MOUNTING

CHAPTER CONTENTS

- 7.1 Tools required — page 30
- 7.2 Removing the front bezel — page 30
- 7.3 Mounting — page 30

7.1 Tools required

The following tools are required for installation.




Description

- 1 Pozi-drive screwdriver.
- 2 File.
- 3 92.00 mm (3.62 in) hole cutter.
- 4 Adhesive tape.
- 5 Power drill.

7.2 Removing the front bezel

Follow the steps listed below to remove the front bezel.



Note:

Use care when removing the bezel. Do not use any tools to lever the bezel; doing so may cause damage.

In order to remove the front bezel:

1. Using your fingers pull the bezel away from the unit at the top and side. The bezel will start to come away from the unit at the top and side.
2. Pull the bezel away from the unit on the opposite side.
3. The bezel will now come free from the unit.


7.3 Mounting

Follow the instructions below to mount the display.

Before mounting the product, ensure that you have:

- Selected a suitable location, based on the location requirements found in this document. For more information, refer to: [p.25 – Location requirements](#)
- Identified the relevant cable connections and the route that the cables will take.

- Removed the bezel and button pad from the display.



1. Fix the supplied mounting template to the selected location, using self adhesive tape.
2. Drill the cut out hole using a 92 mm (3 5/8") hole cutter.

Alternatively, use small drill bit to make pilot holes in each corner of the cut out area and then use a jigsaw to cut along the inside edge of the cut out line.

3. Ensure that the display fits into the removed area.
4. File around any rough edges.
5. Drill the fixing holes as indicated on the mounting template.
6. Peel the backing off of the panel mounting gasket and place the adhesive side of the gasket onto the back of the display and press firmly onto the flange.
7. Connect the SeaTalk NG cable.
8. Position the display in place and secure using the fixings provided.
9. Refit the button pad and bezel.

Note:

- Drill bit, tap size and tightening torques are dependant upon the material type and thickness of the mounting surface.
- The supplied gasket provides a seal between the unit and a suitably flat and stiff mounting surface or binnacle. The gasket should be used in all installations. If the mounting surface or binnacle is not entirely flat and stiff or has a rough surface finish, it may also be necessary to use a marine-grade sealant.

CHAPTER 8: CABLES AND CONNECTIONS — GENERAL INFORMATION

CHAPTER CONTENTS

- [8.1 General cabling guidance — page 33](#)
- [8.2 Connections overview — page 34](#)

8.1 General cabling guidance

Cable types and length


It is important to use cables of the appropriate type and length.

- Unless otherwise stated only use cables supplied by Raymarine.
- Where it is necessary to use non-Raymarine cables, ensure that they are of correct quality and gauge for their intended purpose. (e.g.: longer power cable runs may require larger wire gauges to minimize voltage drop along the run).

Cable routing

Cables must be routed correctly, to maximize performance and prolong cable life.

- Do NOT bend cables excessively. Wherever possible, ensure a minimum bend diameter (\emptyset) of 200 mm (7.87 in) / minimum bend radius (R) of 100 mm (3.94 in).



- Protect all cables from physical damage and exposure to heat. Use trunking or conduit where possible. Do NOT run cables through bilges or doorways, or close to moving or hot objects.
- Secure cables in place using cable clips or cable ties. Coil any excess cable and tie it out of the way.
- Where a cable passes through an exposed bulkhead or deckhead, use a suitable watertight feed-through.

- Do NOT run cables near to engines or fluorescent lights.
- Always route data cables as far away as possible from:
 - Other equipment and cables.
 - High current carrying AC and DC power lines.
 - Antennas.

Strain relief

Use adequate strain relief for cabling to ensure that connectors are protected from strain and will not pull out under extreme sea conditions.

Cable shielding

Ensure that cable shielding is not damaged during installation and that all cables are properly shielded.

Important:

Be aware that some **third-party** cables and adaptors (for example, certain Ethernet cables using RJ45 connectors) are not always shielded. To prevent breaks in cable shielding continuity and potential grounding issues, special attention is required to ensure that any cables, extension cables, adaptors, or other signal-coupling devices (such as multi-way connectors, junction boxes, terminal blocks etc.) used in cable runs **maintain all shield connections throughout the cable run.**

Suppression ferrites

- Raymarine cables may be pre-fitted or supplied with suppression ferrites. These are important for correct EMC performance. If ferrites are supplied separately to the cables (i.e. not pre-fitted), you must fit the supplied ferrites, using the supplied instructions.
- If a ferrite has to be removed for any purpose (e.g. installation or maintenance), it must be replaced in the original position before the product is used.
- Use only ferrites of the correct type, supplied by Raymarine or its authorized dealers.
- Where an installation requires multiple ferrites to be added to a cable, additional cable clips should be used to prevent stress on the connectors due to the extra weight of the cable.

Connecting cables

Follow the steps below to connect the cable(s) to your product.

1. Ensure that the vessel's power supply is switched off.
2. Ensure that the device being connected has been installed in accordance with the installation instructions supplied with that device.
3. Ensuring correct orientation, push cable connectors fully onto the corresponding connectors.
4. Engage any locking mechanism to ensure a secure connection (e.g.: turn locking collars clockwise until tight, or in the locked position).
5. Ensure any bare ended wire connections are suitably insulated to prevent shorting and corrosion due to water ingress.

Bare-ended wire connections

You must ensure that any bare-ended wires are adequately protected from short circuit and water ingress.

Bare-ended wire connections

It is recommended that bare-ended wire connections are made by soldering or using crimp connectors, and then protected by wrapping the connection in electrical insulation tape.

Unused bare-ended wires

Any unused bare-ended wires should be folded back and wrapped in electrical insulation tape.




Warning: Positive ground systems

Do not connect this unit to a system which has positive grounding.

8.2 Connections overview

The instrument display includes the following connections:



SeaTalk NG connections:

Description	
1	SeaTalk NG connector.


Direct transducer connections (i50 Tridata currently illustrated):

Description	
2	The direct transducer connections available will change depending on your i50 variant. For more information, refer to: p.37 – Direct transducer connection

Replacing spade terminals

Although the transducer cable is fitted with spade terminals for direct connection to a compatible display or converter, it may be necessary to remove these to allow the cable to be routed through bulkheads or masts etc. 5 x 1/8th spade terminals will be required (not supplied), to replace those removed.

When fitting the new spade terminals, prepare the cables as detailed below:



1. Prepare the cable as shown in 1 above.
2. Fold back the wire strands and insert into the new spade connector as shown in 2 above.
3. Ensure the wire strands do not extend beyond the rear of the spade connector insulation.
4. Crimp the connector to the wire.


CHAPTER 9: NETWORK CONNECTIONS

CHAPTER CONTENTS

- 9.1 Transducer connection options — page 37
- 9.2 SeaTalk 1 connection — page 40
- 9.3 SeaTalk NG connection — page 41
- 9.4 NMEA 2000 network connection — page 43

9.1 Transducer connection options

Transducers may be connected to the instrument display using **one** of the following methods, which is dependent on your system configuration.



Transducer connects to:	Description
1 i50 (i50 Tridata currently illustrated)	Transducers may be connected directly to the rear of the i50 display. For more information, refer to: p.37 — Direct transducer connection
2 iTC-5	Transducers may be connected to the display via an iTC-5 connected to the same SeaTalk NG network as the instrument display. For more information, refer to: p.39 — iTC-5 transducer connections
3 ST70 transducer pod	Transducers may be connected to the instrument display via an ST70 transducer pod connected to the same SeaTalk NG network as the instrument display. For more information, refer to: p.40 — Transducer pod connections

Direct transducer connections


Analog transducer data can be transmitted to the i50 using a direct transducer connection.

The direct transducer connections available will change depending on your i50 variant:

- [i50 Depth direct transducer connection](#)
- [i50 Speed direct transducer connection](#)
- [i50 Tridata direct transducer connections](#)

i50 Depth direct transducer connection

Analog transducer data can be transmitted to the i50 Depth using a direct transducer connection.




Depth transducer connections:

	Cable color	Signal name
1	Black (Depth)	Piezoceramic –
2	Blue (Depth)	Piezoceramic +
3	Screen (Depth)	0 V (shield)

i50 Speed direct transducer connection

Analog transducer data can be transmitted to the i50 Speed using a direct transducer connection.




Speed transducer connections:

	Cable color	Signal name
1	Red (Speed)	Speed V+
2	Green (Speed)	Speed (signal)
3	Screen (Speed)	Speed 0 V (shield)
4	White (Speed)	Temperature (signal)
5	Brown (Speed)	Temperature 0 V

i50 Tridata direct transducer connections

Analog transducer data can be transmitted to the i50 Tridata using a direct transducer connection.




Depth and speed transducer connections:

	Cable color	Signal name
1	Black (Depth)	Piezoceramic -
2	Blue (Depth)	Piezoceramic +
3	Screen (Depth)	0 V (shield)
4	Red (Speed)	Speed V+
5	Green (Speed)	Speed (signal)
6	Screen (Speed)	Speed 0 V (shield)
7	White (Speed)	Temperature (signal)
8	Brown (Speed)	Temperature 0 V

iTC-5 transducer connections

Analog transducer data can be transmitted to the display via an iTC-5.



1. Speed & Temperature transducer connections
2. Wind transducer connections
3. Compass connections
4. Rudder reference transducer connections
5. Depth transducer connections


For details on connecting an iTC-5 to the SeaTalk NG backbone and connecting transducers to the iTC-5, refer to the documentation provided with the iTC-5:

iTC-5 documentation link

www.bit.ly/itc-5-docs

Transducer pod connections

Analog transducer data can be transmitted to the display using legacy transducer pods.




1. Analog transducer (e.g.: speed and temperature transducer)
2. Transducer pod (e.g.: Speed pod)
3. SeaTalk NG T-Piece connector (A06028)

Connect the transducer to the pod, the pod terminals are color-coded, ensure that each wire is connected to the corresponding terminal.

Connect the pod to the SeaTalk NG backbone using a SeaTalk NG to bare wire spur cable (e.g.: A06043) and a T-piece connector. Pods must be located no farther than 400 mm (15.75 in.) from the connection point on the backbone.

9.2 SeaTalk 1 connection

Connections to an existing SeaTalk 1 system must be made using the separately available SeaTalk 1 (3-pin) to SeaTalk NG adapter cable (A06047).



Description

- 1 Wind transducer (Short-Arm Masthead Wind vane transducer currently illustrated).
- 2 i60 Wind.
- 3 i50 Depth.

Description	
4	i50 Speed
5	i70s.
6	SeaTalk NG spur cable.
7	SeaTalk 1 (3-pin) to SeaTalk NG adapter cable.
8	Depth transducer (P319 currently illustrated).
9	Speed transducer (P317 currently illustrated).
10	SeaTalk 1 3-way junction box.
11	SeaTalk 1 extension cable.
12	12 / 24 V dc power supply.
13	SeaTalk 1 course computer (providing 12 V dc power to the SeaTalk 1 network.)
14	ST6002 (SeaTalk 1 pilot controller).


9.3 SeaTalk NG connection

Connections to an existing SeaTalk NG system must be made using the supplied SeaTalk NG spur cable.

Note:

The ACU-100, ACU-150 and the SPX-5 cannot be used to power the SeaTalk NG backbone.


SeaTalk NG Evolution system



Description	
1	Wind transducer (Short-Arm Masthead Wind vane transducer currently illustrated).
2	Depth transducer (P319 currently illustrated).
3	Speed transducer (P371 currently illustrated).
4	ACU-200 / ACU-300 / ACU-400.
5	Pilot controller (p70 currently illustrated).
6	SeaTalk NG spur cable.
7	i60 Wind.

Description	
8	i50 Depth.
9	i50 Speed.
10	EV-1.
11	12 V dc power supply.
12	Rudder reference transducer.
13	SeaTalk NG backbone cable.
14	SeaTalk NG 5-way connector.


SeaTalk NG SPX system



Description	
1	12 V dc power supply.
2	Wind transducer (Short-Arm Masthead Wind vane transducer currently illustrated).
3	Depth transducer (P319 currently illustrated).
4	Speed transducer (P371 currently illustrated).

Description	
5	Rudder reference transducer.
6	Fluxgate compass.
7	Pilot controller (p70 currently illustrated).
8	i60 Wind.
9	i50 Depth.
10	i50 Speed.
11	SeaTalk NG spur cable.
12	SPX-Series (supplying 12 V dc to the SeaTalk NG network).
13	SeaTalk NG backbone cable.
14	SeaTalk NG 5-way connector.


Connecting SeaTalk NG cables



1. Rotate your product's SeaTalk NG connector locking collar counter clockwise, so that the connector is in the unlocked position.
2. Ensure the cable's connector is correctly oriented (groove pointing up).
3. Fully insert the cable connector.
4. Rotate the locking collar clockwise (2 clicks) until it is in the locked position.

9.4 NMEA 2000 network connection

Your SeaTalk NG device can be connected to a DeviceNet / NMEA 2000 network.



1. SeaTalk NG device.
2. SeaTalk NG to DeviceNet (male) adapter cable (A06078, A06074, A06076, or A06046).
3. DeviceNet T-piece.
4. NMEA 2000 backbone.

CHAPTER 10: POWER CONNECTIONS (SEATALK NG CONNECTIONS)

CHAPTER CONTENTS

- 10.1 Power options — page 45
- 10.2 SeaTalk NG power connection — page 45
- 10.3 SeaTalk NG power supply — page 46
- 10.4 Inline fuse requirement — page 46
- 10.5 Inline fuse and thermal breaker ratings — page 46
- 10.6 SeaTalk NG power cables — page 47
- 10.7 SeaTalk NG product loading — page 47
- 10.8 SeaTalk NG power connection point — page 48
- 10.9 SeaTalk NG system loading — page 48
- 10.10 Power distribution — SeaTalk NG — page 49
- 10.11 Power connection via Autopilot Control Unit (ACU-Series) — page 51

10.1 Power options

This product must have only **one** power source.

Important:

Before attempting to power your product from a SeaTalk NG backbone or SeaTalk 1 network, please note the following important requirements and considerations:

- You must connect only **one** power source.
- If your SeaTalk NG backbone is connected to any other system, ensure that in the combined system you connect only **one** data source for any given data type (for example GNSS (GPS)), unless specified otherwise.
- If any SeaTalk NG and SeaTalk 1 products are connected together, do NOT connect to an NMEA 2000 backbone. This product combination may compromise the integrity of your NMEA 2000 system.
- If you are connecting your product to a SeaTalk NG backbone via the SeaTalk 1 to SeaTalk NG converter (E22158), the converter must ONLY be powered by the SeaTalk NG bus.
- You can connect two separate SeaTalk 1 networks to a SeaTalk NG backbone using different adapter cables and bridging methods (e.g. via an ST70 instrument or a SeaTalk 1 to SeaTalk NG converter), but the SeaTalk 1 networks must NOT be connected together. For more information, refer to the SeaTalk NG Reference Manual (81300).

The following power options are available for your product. The required option is dependent on your system configuration:


1. **SeaTalk NG** power option:
 - Connection to a SeaTalk NG backbone, using the supplied SeaTalk NG spur cable. For more information, refer to: [p.44 – Power connections \(SeaTalk NG connections\)](#)
2. **SeaTalk 1** power option:
 - Connection to a SeaTalk 1 network, using the separately available SeaTalk 1 (3-pin) to SeaTalk NG adapter cable (A06047). For more information, refer to: [p.52 – Power connections \(SeaTalk 1 connections\)](#)
3. **Direct connection** power option:

[Power connections \(SeaTalk NG connections\)](#)

- Direct connection to a vessel's 12 V dc power supply, using the separately available SeaTalk NG power cable (A06049). For more information, refer to: [p.55 – Power connections \(Direct connections\)](#)

10.2 SeaTalk NG power connection

Your instrument display can be powered directly from a SeaTalk NG backbone, using the supplied SeaTalk NG spur cable.



Description

- | Description | |
|-------------|------------------------------|
| 1 | Instrument display. |
| 2 | SeaTalk NG spur cable. |
| 3 | SeaTalk NG backbone cable. |
| 4 | SeaTalk NG T-piece (A06028). |

10.3 SeaTalk NG power supply

Your product is supplied power via the SeaTalk NG backbone (or the NMEA 2000 backbone if applicable).

A SeaTalk NG backbone requires a single 12 V dc power supply. Power can be supplied to the SeaTalk NG backbone by one of the following methods:

- (1) Direct connection to a 12 V dc battery using an inline 5 amp fuse.
- Connection to a 12 V dc distribution panel using a 3 amp thermal breaker.
- (2) Connection to the SeaTalk NG connector of an ACU-Series Autopilot Control Unit (not ACU-100 or ACU-150), or an SPX-Series course computer (not SPX-5).
- For 24 V vessels, connection must be via a 5 amp, regulated, continuous 24 V dc to 12 V dc converter.

Note:


- (1) The battery used for starting the vessel's engine(s) should NOT be used to power the SeaTalk NG backbone, as this can cause sudden voltage drops when the engines are started.
- (2) The ACU-100, ACU-150 or SPX-5 cannot be used to power the SeaTalk NG backbone.
- The course computer SeaTalk NG connector includes a power switch that must be in the On position to provide power to the backbone.

10.4 Inline fuse requirement

If your product is NOT supplied with an inline fuse (whether separately or fitted to the power cable), you MUST fit a suitably-rated inline fuse to your product's red power wire, housed in a waterproof fuse holder.

The illustration below shows the two main types of inline fuse with waterproof holder, for use in marine electronics installations. Fuses in a variety of ratings are widely available at chandleries and marine electrical retailers.

Select one of the following fuse types to protect your Raymarine product:



1. Waterproof fuse holder containing a “glass”-type inline fuse.
2. Waterproof fuse holder containing a “blade”-type inline fuse.

Fuse ratings:

- *Voltage rating* — must be equal to or greater than the voltage of your vessel's power supply.
- *Current rating* — refer to the *Inline fuse and thermal breaker rating* section in this document.

10.5 Inline fuse and thermal breaker ratings

The SeaTalk NG network's power supply requires a suitably-rated inline fuse or thermal breaker to be fitted.

Inline fuse rating	Thermal breaker rating
5A	3A (refer to note below)

Note:


The suitable fuse rating for the thermal breaker is dependent on:

1. How many devices you have connected to your SeaTalk NG network, and;
2. How many devices are sharing the same thermal breaker that your SeaTalk NG network is connected to.

10.6 SeaTalk NG power cables

The following SeaTalk NG power cables can be used to connect the backbone to your chosen **12 V dc** power supply:

Direct connection cables



1. Standard (straight) SeaTalk NG power cable, 2 m (6.6 ft) (part number: **A06049**).
2. Elbow (right-angled) SeaTalk NG power cable, 2 m (6.6 ft) (part number: **A06070**).

Wiring

- **+ Red (positive) wire** — connects to the battery or distribution panel positive terminal. A waterproof fuse holder with 5 A inline fuse (not supplied) must be fitted to this red wire.
- **- Black (negative) wire** — connects to battery or distribution panel negative terminal.
- **Drain wire** — connects to the vessel's RF common ground point (if available), or the battery's negative (-) terminal.

Autopilot Control Unit connection cable



1. ACU-Series/SPX-Series autopilot to SeaTalk NG spur cable, 0.3 m (1.0 ft) (part number **R12112**). Connects the course computer to the SeaTalk NG backbone. This connection can also be used to provide 12 V dc power to the SeaTalk NG backbone.

10.7 SeaTalk NG product loading

The number of products that can be connected to a SeaTalk NG backbone depends on the current draw of each product and the physical length of the backbone cabling.

NMEA 2000 Load Equivalency Numbers (LEN) are used to express the amount of current that is drawn from SeaTalk NG products (**1 LEN = 50 mA**). The LEN for each product can be found in the product's *Technical Specification*.

Products which have a dedicated power supply connection that are connected to the SeaTalk NG backbone will still have an LEN rating. This is because the product's NMEA 2000/SeaTalk NG internal transceiver will still be powered by the SeaTalk NG backbone.

LENs are used to determine the power connection point for the SeaTalk NG backbone.

10.8 SeaTalk NG power connection point

The point along the backbone where the power connection should be made is based on the length of the backbone.

Note:


- A 12 V dc power supply must be connected to a *white* spur SeaTalk NG connection on the backbone.
- Do NOT connect the power connection to a *blue* SeaTalk NG backbone connector.
- **With the exception of** the iTC-5 and the backbone itself, do NOT connect the power supply directly to a product's *white* SeaTalk NG spur connector.

Small systems

If the backbone length is 60 m (197 ft) or less, the power connection may be made at any point in the backbone.

Large systems

If the backbone length is greater than 60 m (197 ft), the power connection should be made at a point that creates a balanced current draw from each side of the backbone. Load Equivalency Numbers (LEN) are used to determine the power connection point for the system.



In the example above, the system has an overall LEN of 16, so the optimum connection point would be to have a loading of 8 LEN either side of the connection point.

10.9 SeaTalk NG system loading

The maximum loading (LEN) for a SeaTalk NG system depends on the length of the backbone.

Unbalanced system loading:

- **Backbone Length:** 0 m (0 ft) to 20 m (66 ft) — **Maximum LEN:** 40
- **Backbone Length:** > 20 m (66 ft) to 40 m (131 ft) — **Maximum LEN:** 20
- **Backbone Length:** > 40 m (131 ft) to 60 m (197 ft) — **Maximum LEN:** 14

Balanced system loading:

- **Backbone Length:** 0 m (0 ft) to 60 m (197 ft) — **Maximum LEN:** 100
- **Backbone Length:** > 60 m (197 ft) to 80 m (262 ft) — **Maximum LEN:** 84
- **Backbone Length:** > 80 m (262 ft) to 100 m (328 ft) — **Maximum LEN:** 60
- **Backbone Length:** > 100 m (328 ft) to 120 m (394 ft) — **Maximum LEN:** 50

- **Backbone Length:** > 120 m (394 ft) to 160 m (525 ft) — **Maximum LEN:** 40
- **Backbone Length:** > 160 m (525 ft) to 200 m (656 ft) — **Maximum LEN:** 32

10.10 Power distribution — SeaTalk NG


Recommendations and best practice.

- Only use approved SeaTalk NG power cables. Do NOT use a power cable designed for, or supplied with, a different product.
- See below for more information on implementation for some common power distribution scenarios.

Important:


- When planning and wiring, take into consideration other products in your system, some of which (e.g. sonar modules) may place large power demand peaks on the vessel's electrical system, which may impact the voltage available to other products during the peaks.
- The information provided below is for guidance only, to help protect your product. It covers common vessel power arrangements, but does NOT cover every scenario. If you are unsure how to provide the correct level of protection, please consult an authorized Raymarine dealer or a suitably qualified professional marine electrician.

Implementation — connection to distribution panel (recommended)



Power connections (SeaTalk NG connections)

1. Waterproof fuse holder with 5 A inline fuse must be fitted (not supplied).
 2. SeaTalk NG power cable.
 3. RF Ground connection point for drain wire.
- Ideally, the SeaTalk NG power cable should be connected to a suitable breaker or switch on the vessel's distribution panel or factory-fitted power distribution point. It is recommended that a 5 A inline fuse is fitted to the red (positive) wire of the SeaTalk NG power cable.
 - The distribution point should be fed from the vessel's primary power source by 8 AWG (8.36 mm²) cable.
 - Ideally, all equipment should be wired to individual suitably-rated thermal breakers or fuses, with appropriate circuit protection. Where this is not possible and more than one item of equipment shares a breaker, use individual in-line fuses for each power circuit to provide the necessary protection.




1. Positive (+) bar
2. Negative (-) bar
3. Circuit breaker
4. Waterproof fuse holder with 5 A inline fuse must be fitted (not supplied).

Important:

Observe the recommended fuse / breaker ratings provided in the product's documentation, however be aware that the suitable fuse / breaker rating is dependent on the number of devices being connected.

Implementation — direct connection to battery

- Where connection to a power distribution panel is not possible, the power cable may be connected to the vessel's battery.
- You **MUST** fit a 5 A inline fuse between the red wire and the battery's positive terminal.
- If you need to extend the length of the power cable, ensure you use suitably rated cable and that sufficient power (12 V dc) is available at the SeaTalk NG backbone's power connection.



1. Waterproof fuse holder with 5 A inline fuse must be fitted (not supplied).
2. SeaTalk NG power cable.

3. Connection point for drain wire.

Battery connection scenario A:

Suitable for a vessel with a common RF ground point. In this scenario, the power cable's drain wire should be connected to the vessel's common RF ground point.

Battery connection scenario B:

Suitable for a vessel without a common RF ground point. In this scenario the power cable's drain wire should be connected directly to the battery's negative terminal.

SeaTalk NG Power cable extension

If you need to extend the length of the SeaTalk NG power cable, ensure you use suitably-rated cable, and that sufficient power is available at the SeaTalk NG backbone's power connection point:

- For power cable extensions, a **minimum** wire gauge of 16 AWG (1.31 mm²) is recommended. For cable runs longer than 15 m (49.2 ft), you may need to consider a thicker wire gauge (e.g. 14 AWG (2.08 mm²), or 12 AWG (3.31 mm²).
- To ensure power cables (including any extension) are of a sufficient gauge, ensure that there is a continuous **minimum** voltage of **10.8 V dc** at the end of the cable where it enters the product's power connector, even with a fully flat battery at 11 V dc. (Do not assume that a flat battery is at 0 V dc. Due to the discharge profile and internal chemistry of batteries, the current drops much faster than the voltage. A "fully flat" battery still shows a positive voltage, even if it doesn't have enough current to power your device.)

Important:

Be aware that some products in your system (such as sonar modules) can create voltage peaks at certain times, which may impact the voltage available to other products during the peaks.

More information

It is recommended that best practice is observed in all vessel electrical installations, as detailed in the following standards:

- BMEA Code of Practice for Electrical and Electronic Installations in Boats

- NMEA 0400 Installation Standard
- ISO 13297: Small craft — Electrical systems — Alternating and direct current installations
- ISO 10133: Small craft — Electrical systems — Extra-low-voltage d.c. installations
- ABYC E-11 AC & DC Electrical Systems on Boats
- ABYC A-31 Battery chargers and Inverters
- ABYC TE-4 Lightning Protection



Warning: 12 Volt dc only

This product must ONLY be connected to a 12 V dc power source.



Warning: Product grounding

Before applying power to this product, it MUST be correctly grounded, in accordance with the instructions provided.



Warning: Positive ground systems

Do not connect this unit to a system which has positive grounding.

10.11 Power connection via Autopilot Control Unit (ACU-Series)


The SeaTalk NG backbone can be supplied 12 V dc power from a compatible Raymarine Autopilot Control Unit (ACU-Series).

Important:

The SeaTalk NG backbone must have a single power supply connection. If your SeaTalk NG backbone is supplied power directly from a battery or distribution panel, then you must ensure that the SeaTalk NG power switch on your ACU-Series is switched Off.

Note:

ACU-100, ACU-150 and SPX-5 autopilot control units cannot supply power to the SeaTalk NG backbone.



1. Fuse for SeaTalk NG power supply.
2. Power switch for SeaTalk NG power supply:
 - a. Select the [OFF] position if your SeaTalk NG backbone is supplied power directly from a battery or distribution panel.
 - b. Select the [ON] position if your SeaTalk NG backbone is supplied power by the ACU-Series.
3. ACU-Series/SPX-Series autopilot to SeaTalk NG spur cable (part number: R12112).

CHAPTER 11: POWER CONNECTIONS (SEATALK 1 CONNECTIONS)

CHAPTER CONTENTS

- 11.1 Power options — page 53
- 11.2 SeaTalk 1 power connection — page 53
- 11.3 Inline fuse requirement — page 54
- 11.4 Inline fuse and thermal breaker ratings — page 54

11.1 Power options

This product must have only **one** power source.

Important:

Before attempting to power your product from a SeaTalk NG backbone or SeaTalk 1 network, please note the following important requirements and considerations:

- You must connect only **one** power source.
- If your SeaTalk NG backbone is connected to any other system, ensure that in the combined system you connect only **one** data source for any given data type (for example GNSS (GPS)), unless specified otherwise.
- If any SeaTalk NG and SeaTalk 1 products are connected together, do NOT connect to an NMEA 2000 backbone. This product combination may compromise the integrity of your NMEA 2000 system.
- If you are connecting your product to a SeaTalk NG backbone via the SeaTalk 1 to SeaTalk NG converter (E22158), the converter must ONLY be powered by the SeaTalk NG bus.
- You can connect two separate SeaTalk 1 networks to a SeaTalk NG backbone using different adapter cables and bridging methods (e.g. via an ST70 instrument or a SeaTalk 1 to SeaTalk NG converter), but the SeaTalk 1 networks must NOT be connected together. For more information, refer to the SeaTalk NG Reference Manual (81300).

The following power options are available for your product. The required option is dependent on your system configuration:


1. **SeaTalk NG** power option:
 - Connection to a SeaTalk NG backbone, using the supplied SeaTalk NG spur cable. For more information, refer to: [p.44 – Power connections \(SeaTalk NG connections\)](#)
2. **SeaTalk 1** power option:
 - Connection to a SeaTalk 1 network, using the separately available SeaTalk 1 (3-pin) to SeaTalk NG adapter cable (A06047). For more information, refer to: [p.52 – Power connections \(SeaTalk 1 connections\)](#)
3. **Direct connection** power option:

[Power connections \(SeaTalk 1 connections\)](#)

- Direct connection to a vessel's 12 V dc power supply, using the separately available SeaTalk NG power cable (A06049). For more information, refer to: [p.55 – Power connections \(Direct connections\)](#)

11.2 SeaTalk 1 power connection

Your instrument display can be powered directly from a SeaTalk 1 network, using the separately available SeaTalk 1 (3 pin) to SeaTalk NG adapter cable (A06047).



Description

- 1 Waterproof fuse holder containing a suitably-rated inline fuse (**not supplied**), which must be fitted to the red positive wire — refer to the fuse ratings below.
- 2 Red wire (positive) — connects to the power supply's positive terminal.
- 3 Black wire (negative) — connects to the power supply's negative terminal.


Description	
4	SeaTalk 1 power cable, 1 m (3.28 ft).
5	12 V dc power supply.
6	Instrument display.
7	SeaTalk 1 junction box (D224).
8	SeaTalk 1 (3 pin) to SeaTalk NG adapter cable (A06047).

11.3 Inline fuse requirement

If your product is NOT supplied with an inline fuse (whether separately or fitted to the power cable), you MUST fit a suitably-rated inline fuse to your product’s red power wire, housed in a waterproof fuse holder.

The illustration below shows the two main types of inline fuse with waterproof holder, for use in marine electronics installations. Fuses in a variety of ratings are widely available at chandleries and marine electrical retailers.

Select one of the following fuse types to protect your Raymarine product:



1. Waterproof fuse holder containing a “glass”-type inline fuse.
2. Waterproof fuse holder containing a “blade”-type inline fuse.

Fuse ratings:

- *Voltage rating* — must be equal to or greater than the voltage of your vessel’s power supply.

- *Current rating* — refer to the *Inline fuse and thermal breaker rating* section in this document.

11.4 Inline fuse and thermal breaker ratings

The SeaTalk 1 network’s power supply requires a suitably-rated inline fuse or thermal breaker to be fitted.

Inline fuse rating	Thermal breaker rating
5A	5A (refer to note below)

Note:

The suitable fuse rating for the thermal breaker is dependent on:

1. How many devices you have connected to your SeaTalk 1 network, and;
2. How many devices are sharing the same thermal breaker that your SeaTalk 1 network is connected to.

Raymarine recommends that the power is connected to a SeaTalk 1 system in such a way that the current drawn on each side of the power connection point is equal.

CHAPTER 12: POWER CONNECTIONS (DIRECT CONNECTIONS)

CHAPTER CONTENTS

- 12.1 Power options — page 56
- 12.2 Direct power connection — page 56
- 12.3 Inline fuse requirement — page 57
- 12.4 Inline fuse and thermal breaker ratings — page 57
- 12.5 Power distribution — page 57
- 12.6 Power cable extension (12 / 24 V systems) — page 60

12.1 Power options

This product must have only **one** power source.

Important:

Before attempting to power your product from a SeaTalk NG backbone or SeaTalk 1 network, please note the following important requirements and considerations:

- You must connect only **one** power source.
- If your SeaTalk NG backbone is connected to any other system, ensure that in the combined system you connect only **one** data source for any given data type (for example GNSS (GPS)), unless specified otherwise.
- If any SeaTalk NG and SeaTalk 1 products are connected together, do NOT connect to an NMEA 2000 backbone. This product combination may compromise the integrity of your NMEA 2000 system.
- If you are connecting your product to a SeaTalk NG backbone via the SeaTalk 1 to SeaTalk NG converter (E22158), the converter must ONLY be powered by the SeaTalk NG bus.
- You can connect two separate SeaTalk 1 networks to a SeaTalk NG backbone using different adapter cables and bridging methods (e.g. via an ST70 instrument or a SeaTalk 1 to SeaTalk NG converter), but the SeaTalk 1 networks must NOT be connected together. For more information, refer to the SeaTalk NG Reference Manual (81300).


The following power options are available for your product. The required option is dependent on your system configuration:

1. **SeaTalk NG** power option:
 - Connection to a SeaTalk NG backbone, using the supplied SeaTalk NG spur cable. For more information, refer to: [p.44 – Power connections \(SeaTalk NG connections\)](#)
2. **SeaTalk 1** power option:
 - Connection to a SeaTalk 1 network, using the separately available SeaTalk 1 (3-pin) to SeaTalk NG adapter cable (A06047). For more information, refer to: [p.52 – Power connections \(SeaTalk 1 connections\)](#)
3. **Direct connection** power option:

- Direct connection to a vessel's 12 V dc power supply, using the separately available SeaTalk NG power cable (A06049). For more information, refer to: [p.55 – Power connections \(Direct connections\)](#)

12.2 Direct power connection

Your instrument display can be powered directly from a 12 V dc power source, using the separately available SeaTalk NG power cable (A06049).



Description

- 1 SeaTalk NG power cable (A06049), available separately.
- 2 Drain wire — connects to the vessel's RF common ground point (if available), or the battery's negative terminal.
- 3 Black (negative) wire — connects to the battery or distribution panel negative terminal.
- 4 Waterproof fuse holder containing a suitably-rated inline fuse (not supplied), which must be fitted to the red positive wire — refer to the fuse ratings below.
- 5 Red (positive) wire — connects to the battery or distribution panel positive terminal. A waterproof fuse holder containing a suitably-rated inline fuse must be fitted to the red positive wire.


Description	
6	Vessel's RF common ground point.
7	i50-Series.
8	12 V dc power supply

12.3 Inline fuse requirement

If your product is NOT supplied with an inline fuse (whether separately or fitted to the power cable), you MUST fit a suitably-rated inline fuse to your product's red power wire, housed in a waterproof fuse holder.

The illustration below shows the two main types of inline fuse with waterproof holder, for use in marine electronics installations. Fuses in a variety of ratings are widely available at chandleries and marine electrical retailers.

Select one of the following fuse types to protect your Raymarine product:



1. Waterproof fuse holder containing a “glass”-type inline fuse.
2. Waterproof fuse holder containing a “blade”-type inline fuse.

Fuse ratings:

- *Voltage rating* — must be equal to or greater than the voltage of your vessel's power supply.
- *Current rating* — refer to the *Inline fuse and thermal breaker rating* section in this document.

Power connections (Direct connections)

12.4 Inline fuse and thermal breaker ratings

The following inline fuse and thermal breaker ratings apply to your product:

Inline fuse rating	Thermal breaker rating
3A	3A

Important:

The suitable fuse rating for the thermal breaker is dependent on the number of devices you are connecting. If in doubt, consult an authorized Raymarine dealer.

12.5 Power distribution


Recommendations and best practice for the power connection of products supplied with a drain wire as part of the supplied power cable.

- The product is supplied with a power cable, either as a separate item or a captive cable permanently attached to the product. Only use the power cable supplied with the product. Do NOT use a power cable designed for, or supplied with, a different product.
- Refer to the *Power connection* section for more information on how to identify the wires in your product's power cable, and where to connect them.
- See below for more information on implementation for some common power distribution scenarios:

Important:

- When planning and wiring, take into consideration other products in your system, some of which (e.g. sonar modules) may place large power demand peaks on the vessel's electrical system, which may impact the voltage available to other products during the peaks.
- The information provided below is for guidance only, to help protect your product. It covers common vessel power arrangements, but does NOT cover every scenario. If you are unsure how to provide the correct level of protection, please consult an authorized dealer or a suitably qualified professional marine electrician.


Implementation — connection to distribution panel (Recommended)



Description

- 1 Waterproof fuse holder containing a suitably-rated inline fuse must be fitted. For suitable fuse rating, refer to: *Inline fuse and thermal breaker ratings*.
- 2 Product power cable.
- 3 Drain wire connection point.

- It is recommended that the supplied power cable is connected to a suitable breaker or switch on the vessel's distribution panel or factory-fitted power distribution point.
- The distribution point should be fed from the vessel's primary power source by 8 AWG (8.36 mm²) cable.
- Ideally, all equipment should be wired to individual suitably-rated thermal breakers or fuses, with appropriate circuit protection. Where this is not possible and more than 1 item of equipment shares a breaker, use individual inline fuses for each power circuit to provide the necessary protection.
- The power cable supplied with your product includes a drain wire, which must be connected to the vessel's common RF ground.




Description

- 1 Positive (+) bar
- 2 Negative (-) bar
- 3 Circuit breaker
- 4 Waterproof fuse holder containing a suitably-rated inline fuse must be fitted. For suitable fuse rating, refer to: *Inline fuse and thermal breaker ratings*.

Important:

Observe the recommended fuse / breaker ratings provided in the product's documentation, however be aware that the suitable fuse / breaker rating is dependent on the number of devices being connected.

Implementation — direct connection to battery



- Where connection to a power distribution panel is not possible, the power cable supplied with your product may be connected directly to the vessel's battery, via a suitably rated fuse or breaker.
- If the power cable is NOT supplied with a fitted inline fuse, you MUST fit a suitably rated fuse or breaker between the red wire and the battery's positive terminal.
- Refer to the inline fuse ratings provided in the product's documentation.
- If you need to extend the length of the power cable supplied with your product, ensure you observe the dedicated *Power cable extensions* advice provided in the product's documentation.

Description

- 1** Waterproof fuse holder containing a suitably-rated inline fuse must be fitted. For suitable fuse rating, refer to: *Inline fuse and thermal breaker ratings*.
- 2** Product power cable.
- 3** Drain wire connection point.

Battery connection scenario A:

Suitable for a vessel with a common RF ground point. In this scenario, the power cable's drain wire should be connected to the vessel's common ground point.

Battery connection scenario B:

Suitable for a vessel without a common grounding point. In this case, the power cable's drain wire should be connected directly to the battery's negative terminal.

Grounding

Ensure that you observe any additional grounding advice provided in the product's documentation.

More information

It is recommended that best practice is observed in all vessel electrical installations, as detailed in the following standards:

- BMEA Code of Practice for Electrical and Electronic Installations in Boats
- NMEA 0400 Installation Standard
- ISO 13297: Small craft — Electrical systems — Alternating and direct current installations
- ISO 10133: Small craft — Electrical systems — Extra-low-voltage d.c. installations
- ABYC E-11 AC & DC Electrical Systems on Boats
- ABYC A-31 Battery chargers and Inverters
- ABYC TE-4 Lightning Protection



Warning: 12 Volt dc only

This product must ONLY be connected to a 12 V dc power source.



Warning: Product grounding

Before applying power to this product, it MUST be correctly grounded, in accordance with the instructions provided.



Warning: Positive ground systems

Do not connect this unit to a system which has positive grounding.

12.6 Power cable extension (12 / 24 V systems)

If you need to extend the length of the power cable supplied with your product, ensure you observe the following advice:

- The power cable for each unit in your system should be run as a separate, single length of 2-wire cable from the unit to the vessel's battery or distribution panel.
- Ensure that the extension cable is of a sufficient gauge for the supply voltage and the total load of the device and the length of the cable run. Refer to the following table for typical **minimum** power cable wire gauges:

Cable length in meters (feet)	Wire gauge in AWG (mm ²) for 12 V supply	Wire gauge in AWG (mm ²) for 24 V supply
<8 (<25)	16 (1.31 mm ²)	18 (0.82 mm ²)
16 (50)	14 (2.08 mm ²)	18 (0.82 mm ²)
24 (75)	14 (2.08 mm ²)	16 (1.31 mm ²)
>32 (>100)	14 (2.08 mm ²)	16 (1.31 mm ²)

Important:

Be aware that some products in your system (such as sonar modules) can create voltage peaks at certain times, which may impact the voltage available to other products during the peaks.

Important:

To ensure power cables (including any extension) are of a sufficient gauge, ensure that there is a continuous **minimum** voltage of **10.8 V dc** at the end of the cable where it enters the product's power connector, even with a fully flat battery at 11 V dc. (Do not assume that a flat battery is at 0 V dc. Due to the discharge profile and internal chemistry of batteries, the current drops much faster than the voltage. A "fully flat" battery still shows a positive voltage, even if it doesn't have enough current to power your device).

CHAPTER 13: I50 DEPTH

CHAPTER CONTENTS

- 13.1 i50 Depth operation — page 62
- 13.2 i50 Depth controls — page 62
- 13.3 Switching on the display — page 63
- 13.4 Switching off the display — page 63
- 13.5 Data master — page 63
- 13.6 Calibration — page 64
- 13.7 Using the depth pages — page 68
- 13.8 Viewing the depth offset — page 68
- 13.9 Alarms — page 69
- 13.10 Illumination — page 71

13.1 i50 Depth operation

When connected to the relevant depth transducer, your i50 Depth instrument:

- Provides current depth information, in either feet (ft), metres (M) or fathoms (FA).
- Records the minimum and maximum depth encountered during the period the unit is switched on.
- Enables you to define alarm thresholds for shallow alarm, deep alarm, shallow anchor alarm and deep anchor alarm.
- Enables you to see what offset has been applied to the depth reading.

Note:

Depth information is obtained from the depth transducer connected to the unit. However, when the instrument is connected to a SeaTalk 1 network which contains a compatible sonar module (fishfinder), the depth information is provided by the sonar module whilst it is switched on.

It should be noted that:

- The required depth units are selected during User calibration.
- Up / Down depth-trend arrows are displayed, if the seabed is rising or falling.
- If for any reason depth information is lost, the depth title will flash and the displayed value will be the last known depth reading.

13.2 i50 Depth controls



Description

- 1** *[Alarm]*— Select to access alarm levels and alarm settings
- 2** *[Offset / Down]*— Select to access depth offset settings. Use to move down through menu options or to decrease numeric values
- 3** *[Depth / Power]*— Select to access depth information, adjust backlight, adjust contrast and power the display On and Off
- 4** *[Reset / Up]*— Select and hold down for 3 seconds to reset data to current values. Use to move up through menu options or to increase numeric values

13.3 Switching on the display

The display will automatically switch on when power is applied to the SeaTalk NG backbone, unless the display has previously been switched off using the *[Power]* button. If the *[Power]* button has been used to switch off the display then it must be used to switch the display back on again.

With the display powered but switched off:

1. Press and hold the *[Power]* button until the screen turns on (approximately 2 seconds).

13.4 Switching off the display

The display can be switched off using the *[Power]* button.

1. Press and hold the *[Power]* button until the count down timer reaches zero and the screen turns off.

Note:

When switched off, the display may still draw a small amount of power from the battery, if this is a concern unplug the SeaTalk NG power supply or switch off at the breaker.


13.5 Data master

Where a system contains more than one unit capable of displaying a data type, the unit physically connected to the transducer must be set as the data *master* and any other units set as a *repeater*.

Changing i50 Depth Master / Repeater status

Displays that have a transducer physically attached to them are automatically set as Data Masters. You can set your display to show depth readings from a different source.

During normal operation:



1. Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 4 seconds, until the *[Software Version]* page is displayed.
2. Press the *[Depth]* button to display the *[Master/Repeater Status]* page.
3. Press the *[Offset]* and *[Reset]* buttons at the same time.
The status will flash.
4. Use the *[Offset]* or *[Reset]* button to change the status between *Master* or *Repeater*.

- Press the *[Offset]* and *[Reset]* buttons at the same time to confirm the status.
- Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds to return to normal operation.
- Power off the display by pressing and holding the *[Power]* button until the screen turns off.
- Power the display back on by pressing and holding the *[Power]* button until the screen turns on (approximately 2 seconds).
- Check the display's status by repeating steps 1 and 2 above.

13.6 Calibration

Before first use the unit must be calibrated to ensure optimum performance.

The calibration settings are grouped into 3 categories: **User Calibration**, **Intermediate Calibration** and **Dealer Calibration**.

Access to the *[User Calibration]* menu can be locked from the *[Dealer Calibration]* menu.

Depth calibration pages

The following calibration procedures can be accessed from the calibration menus referenced below.

User Calibration	Intermediate Calibration	Dealer Calibration
<i>[Depth units]</i>	<i>[Software Version]</i>	<i>[User Calibration Menu Access]</i>
⁽¹⁾ <i>[Depth Offset]</i>	<i>[Master/Repeater Status]</i>	<i>[Display Response]</i>
		<i>[Boat Show Mode]</i>
		<i>[Factory Reset]</i>


Note:

⁽¹⁾ Settings are only available when the instrument status is set to *Master*.

Selecting the unit of measure for depth readings

During normal operation:


- Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds, until *[USER CAL]* is displayed.



Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

- Press the *[Depth]* button until the *[Depth Units]* page is displayed (1 press from the *[USER CAL]*).




- Use the *[Offset]* or *[Reset]* button to select the required unit of measurement for depth readings.
The units of measure available for depth readings are:
 - FEET (default)*
 - METRES*
 - FATHOMS*
- You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Depth Offset

Depths are measured from the transducer face to the bottom (e.g.: seabed). An offset value can be applied to the depth data so that the displayed depth reading represents the depth reading taken from either the keel (negative offset) or the waterline (positive offset).

Before attempting to set a waterline or keel offset, find out the vertical distance between the transducer and either the waterline or the bottom of your vessel's keel, as appropriate. Then set the distance as the depth offset value.




1. *[Waterline offset]*— Values greater than zero (Positive values) represent a waterline offset
2. *[Transducer]*— Zero offset represents the depth from the transducer's location
3. *[Keel offset]*— Values less than zero (Negative values) represent a keel offset

Applying a Depth Offset

During normal operation:


1. Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds, until the *[USER CAL]* is displayed.



Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

2. Press the *[Depth]* button until the *[Depth Offset]* page is displayed (2 presses from *[USER CAL]*).



3. Use the *[Offset]* or *[Reset]* button to select the required depth offset value. The depth offset can be set to the following values:
 - *Keel* — values between -9.9 to -0.1
 - *OFFSET (default)* (Zero Offset) — 0.0
 - *W/L* (Waterline) — values between 0.1 to 9.9
4. You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Checking the software version

To check the software version of your display follow the steps below.

During normal operation:


1. Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 4 seconds, until *[Version]* is displayed.

Locking access to the User Calibration menu


From the *[Dealer Calibration]* menu you can lock access to the *[User Calibration]* menu.

During normal operation:

1. Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 14 seconds, until *[DEALER CAL]* is displayed.



2. Press the *[Offset]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.




3. Use the *[Offset]* or *[Reset]* button to switch access to the *[User Calibration Menu] On (default) and Off*.
Selecting *Off* disables access to the *[User Calibration Menu]*.
4. You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.


Setting the response delay for depth readings

During normal operation:


1. Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 14 seconds, until *[DEALER CAL]* is displayed.



2. Press the *[Offset]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



3. Press the *[Depth]* button until the *[Depth Response]* page is displayed (1 press from the *[User Calibration Menu Access]* page).



4. Use the *[Offset]* and *[Reset]* buttons to adjust the depth response to the required level.
The default level is 12. The levels available are 1 to 15 with level 1 being the slowest update rate and level 15 the quickest.


- You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Enabling and disabling Boat Show Mode


- [Boat show mode]* can only be enabled on Repeater displays.
- [Boat show mode]* is only suitable for demonstration purposes and should NOT be enabled whilst your vessel is in use.

During normal operation:


- Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 14 seconds, until *[DEALER CAL]* is displayed.



- Press the *[Offset]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



- Press the *[Depth]* button until the *[Boat show mode]* page is displayed (2 presses from *[User Calibration Menu Access]* page).




- Use the *[Offset]* or *[Reset]* button to switch *[Boat show mode]* either *On* or *Off* (default).
- You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.


Resetting the display to factory default settings

During normal operation:


- Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 14 seconds, until *[DEALER CAL]* is displayed.



- Press the *[Offset]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.




- Press the *[Depth]* button until *[RESET]* is displayed (3 presses from *[User Calibration Menu Access]* page).



- To reset the display to factory default settings:
 - Use the *[Offset]* or *[Reset]* button to change the reset option to *Yes*.
 - Press the *[Depth]* button to reset your display to factory default settings.
- After a reset it is recommended that you check the data master status of the display to ensure it is set correctly. For details, refer to: [p.63 – Data master](#)
- You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

13.7 Using the depth pages

To cycle through the depth pages follow the steps below.



- [Current Depth]* page.
- ⁽¹⁾ *[Minimum Depth]* page.
- ⁽¹⁾ *[Maximum Depth]* page.

Note:

⁽¹⁾ These pages are temporary pages and will revert back to the *[Current Depth]* page after 8 seconds of inactivity.

- Use the *[Depth]* button to cycle through the available depth pages.
- From the *[Minimum Depth]* or *[Maximum Depth]* page, press and hold the *[Reset]* button for approximately 3 seconds to reset the reading.

13.8 Viewing the depth offset

To view the offset value currently applied to your instrument follow the steps below.

During normal operation:

- Press the *[Offset]* button to display the *[Depth offset]* page.
The display shows the value of the offset applied and identifies:

- If a positive offset value is applied *[W/L]* is displayed to denote a waterline offset.
- If a negative offset value is applied *[KEEL]* is displayed to denote a keel offset.
- If a zero offset value is applied *[OFFSET]* is displayed to denote that there is a zero offset from the transducer.

Note:

Depth offset information is only available on units set as data masters (see *Data master* section for details).

13.9 Alarms

Alarms alert you to a situation or hazard requiring your attention.

You can set up alarms to alert you to certain conditions.

Alarms are raised by system functions, and also external equipment connected to your display.

When an alarm event occurs an audible and visual alarm is activated which indicates the alarm state.

Alarm thresholds can be configured from the relevant alarm page / menu.

Instrument alarms

The alarms available for the i50 Depth and i50 Tridata are listed below.

- *[Shallow depth alarm]*
- *[Deep depth alarm]*
- *[Shallow anchor alarm]*
- *[Deep anchor alarm]*

Alarm indications

An alarm event is indicated by both audible and visual warnings.

Shallow alarm



Deep alarm



Shallow anchor alarm



Deep anchor alarm



Alarms are sounded when the set alarm threshold value is crossed. Alarms will sound until silenced.

Silencing alarms

1. Press any button to silence an active alarm.

Enabling / Disabling alarms


Alarms can be enabled or disabled at any time.

With the relevant alarm page displayed:

1. Press and hold the *[Reset]* button for 1 second to switch the alarm *on* or *off*.

Setting alarm thresholds — i50 Depth

You can adjust the threshold at which alarms are triggered by following the steps below.



With the relevant alarm page displayed:

1. Press the *[Offset]* and *[Reset]* buttons at the same time to change the alarm threshold.
The current threshold will start to flash.
2. Use the *[Reset]* button to increase the alarm threshold.
3. Use the *[Offset]* button to decrease the alarm threshold.
4. The alarm threshold page will time-out after approximately 6 seconds of inactivity, automatically saving the new alarm threshold.

Shallow alarm lock

The *[Shallow Alarm Lock]* feature is designed to prevent unintentional adjustment of the shallow alarm threshold value.

When setting the shallow alarm threshold:

1. Press and hold the *[Reset]* button for 3 seconds to lock the shallow alarm threshold value.
2. The *[Shallow Alarm Lock]* can be turned off again by pressing and holding the *[Reset]* button when adjusting the threshold.

13.10 Illumination

Adjusting the backlight level

The backlighting level can be accessed using the *[Power]* button.

During normal operation:

1. Press and hold the *[Power]* button for approximately 2 seconds until *[LAMPS]* is displayed.
2. Use the *[Up]* button to increase the backlight setting, or.
3. Use the *[Down]* button to decrease the backlight setting.

The backlight level can be adjusted from level 1 to level 9 or switched *Off (default)*.

Note:

The backlight page will time-out after 8 seconds of inactivity.

Adjusting the contrast

During normal operation:

1. Press and hold the *[Power]* button for approximately 4 seconds until *[CONTRAST]* is displayed.
2. Use the *[Power]* button to cycle through the available contrast levels.

The contrast level can be adjusted from level 0 (default) to 3.

Note:

The contrast page will time-out after 8 seconds of inactivity.

Group illumination

Group illumination is used to synchronize and control the backlighting level of multiple units assigned to the same group.

The unit can participate in shared illumination via a SeaTalk 1 network or group illumination via a SeaTalk NG network.

When connected on a SeaTalk 1 network all compatible units will share their backlight level (when 1 unit's backlighting level is adjusted all other units backlight level will also change).

When connected on a SeaTalk NG network the unit can participate in group illumination and be assigned to a group of units which will share their backlighting levels. Available groups are as follows:

- *OFF (default)* — Group illumination is switched off
- *HL1* — Helm 1
- *HL2* — Helm 2
- *CPT* — Cockpit
- *FLY* — Flybridge
- *NST* — Mast
- *GP1* to *GP5* — User defined groups

When assigned to a group, when the backlighting of 1 unit is adjusted the backlighting level of all units assigned to the same group will also change.

Assigning the i50 Depth to a group

To assign the i50 Depth as part of a group so that it can participate in group illumination follow the steps below.

During normal operation:

1. Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for 6 seconds, until the Group illumination page is displayed.
[GROUP CAL] is displayed on-screen.

Note:

The *[Group illumination]* entry page is a temporary page and will time-out to the previous page after 8 seconds.

2. Press the *[Depth]* button to display the *[Groups]* page.
3. Press the *[Offset]* and *[Reset]* buttons at the same time to enable selection of a group.
The group setting will flash.
4. Use the *[Reset]* button to cycle upwards through the list of available groups.
5. Use the *[Offset]* button to cycle back down through the list.
6. Press the *[Offset]* and *[Reset]* buttons at the same time to assign the display to the selected group.
The group setting will stop flashing.

7. Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 2 seconds to return to normal operation.

CHAPTER 14: I50 SPEED

CHAPTER CONTENTS

- 14.1 i50 Speed operation — page 74
- 14.2 i50 Speed controls — page 74
- 14.3 Switching on the display — page 75
- 14.4 Switching off the display — page 75
- 14.5 Calibration — page 75
- 14.6 Using the speed pages — page 86
- 14.7 Using the log, trip and temperature pages — page 87
- 14.8 Using the timers — page 87
- 14.9 Illumination — page 88

14.1 i50 Speed operation


When connected to the relevant speed or speed and temperature transducer, your i50 Speed instrument provides:

- Current, maximum and average speed information, in either knots (KTS), mile per hour (MPH) or kilometers per hour (KPH).
- Log and trip information, in either nautical miles (NM), statute miles (M) or kilometers (KM).
- Water temperature information, in either degrees celsius (°C) or fahrenheit (°F).
- Velocity made good (VMG) information, VMG is only available when connected to SeaTalk 1 or SeaTalk NG network which also contains a compatible wind transducer.
- Speed over ground (SOG) information, SOG is only available when connected to SeaTalk 1 or SeaTalk NG network which also contains a suitable GPS.
- Count-up and race start timers.

It should be noted that:

- The maximum speed, average speed and trip reading are reset to zero at power up.
- The log screen shows the total distance covered by the vessel since the unit was fitted.
- A unit with a transducer physically connected cannot be set as a Repeater display.

14.2 i50 Speed controls



Description

- 1** *[Trip]* – Select to access log, trip and water temperature information
- 2** *[Timer / Down]* – Select to access timers. Use to move down through menu options or to decrease numeric values
- 3** *[Speed / Power]* – Select to access speed information, adjust backlight, adjust contrast and power the display On and Off
- 4** *[Reset / Up]* – Select and hold down for 3 seconds to reset data to current values. Use to move up through menu options or to increase numeric values

14.3 Switching on the display

The display will automatically switch on when power is applied to the SeaTalk NG backbone, unless the display has previously been switched off using the *[Power]* button. If the *[Power]* button has been used to switch off the display then it must be used to switch the display back on again.

With the display powered but switched off:

1. Press and hold the *[Power]* button until the screen turns on (approximately 2 seconds).

14.4 Switching off the display

The display can be switched off using the *[Power]* button.

1. Press and hold the *[Power]* button until the count down timer reaches zero and the screen turns off.

Note:

When switched off, the display may still draw a small amount of power from the battery, if this is a concern unplug the SeaTalk NG power supply or switch off at the breaker.

14.5 Calibration

Before first use the unit must be calibrated to ensure optimum performance.

The calibration settings are grouped into 3 categories: **User Calibration**, **Intermediate Calibration** and **Dealer Calibration**.

Access to the *[User Calibration]* menu can be locked from the *[Dealer Calibration]* menu.

Speed calibration pages

The following calibration procedures can be accessed from the calibration menus referenced below.

User Calibration	Intermediate Calibration	Dealer Calibration
<i>[Speed units]</i>	<i>[Software Version]</i>	<i>[User Calibration Menu Access]</i>
<i>[Speed Resolution]</i>	<i>[Master/Repeater Status]</i>	<i>[Display Response – Speed]</i>
<i>[Log units]</i>	<i>[Speed Run Calibration]</i>	<i>[Display Response – VMG]</i>
⁽¹⁾ <i>[Calibration Factor / SOG]</i>		<i>[Boat Show Mode]</i>
<i>[Water Temperature units]</i>		<i>[Factory Reset]</i>
<i>[Water Temperature Calibration]</i>		
<i>[Timer]</i>		


Note:

⁽¹⁾ Settings are only available when the instrument status is set to *Master*.

Selecting the unit of measure for speed readings

During normal operation:


1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds, until *[USER CAL]* is displayed.



Note:

The [User Calibration] menu will time-out after 8 seconds of inactivity.

2. Press the [Speed] button until [BOAT] is displayed (1 press from [USER CAL]).



3. Use the [Timer] or [Reset] button to select the required unit of measurement for speed readings.

The units of measure available for speed readings are:


- KTS — Knots (default)
- MPH — Miles Per Hour
- KMH — Kilometers Per Hour

4. You can exit the User Calibration Menu, at any time by pressing and holding the [Speed] and [Trip] buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the [Speed] button to cycle to the next setting in the menu.

Changing speed resolution


During normal operation:

1. Press and hold the [Speed] and [Trip] buttons at the same time for approximately 2 seconds, until [USER CAL] is displayed.



Note: The [User Calibration] menu will time-out after 8 seconds of inactivity.

2. Press the [Speed] button until [SPEED] is displayed (2 presses from [USER CAL]).



3. Use the [Timer] or [Reset] button to select the required resolution for speed readings.


The resolutions available are 0.01 (default) and 0.1.

4. You can exit the [User Calibration] menu, at any time by pressing and holding the [Speed] and [Trip] buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the [Speed] button to cycle to the next setting in the menu.

Selecting the unit of measure for log readings

During normal operation:


1. Press and hold the [Speed] and [Trip] buttons at the same time for approximately 2 seconds, until [USER CAL] is displayed.



Note:

The [User Calibration] menu will time-out after 8 seconds of inactivity.

- Press the *[Speed]* button until the *[Log Units]* page is displayed (3 presses from *[USER CAL]*).



- Use the *[Timer]* or *[Reset]* button to select the required unit of measurement for log readings.
 - SM (default)* — Statute Miles
 - NM* — Nautical Miles
 - KM* — Kilometers
- You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Speed]* button to cycle to the next setting in the menu.

1 Point speed calibration


The display's speed readings can be calibrated using a quick, 1 point calibration process, in most situations this is all that will be required to calibrate your speed readings.

Prerequisites:

- For best results SOG data should be available, or an alternative method of estimating vessel speed must be used; e.g. vessel speed can be estimated using nautical measured mile markers or similar landmarks of a known distance apart. For more information, refer to: [p.78 — Nautical Measured Mile Markers](#)
- You will need to be underway, with sufficient space to maneuver unhindered.
- In order to achieve accurate results, water conditions must be calm with zero tide and zero current.

During normal operation:

- Steer your vessel on a steady course at a constant typical speed.
- Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds, until *[USER CAL]* is displayed.




Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.


- Press the *[Speed]* button until 1 of the *[Current Speed]* pages is displayed (4 presses from *[USER CAL]*).

If SOG data is available over SeaTalk NG then the *[SOG]* page is displayed, if SOG data is not available then the *[Calibration Factor]* page is displayed.



- If the *[SOG]* page is displayed and the water conditions are acceptable, press and hold the *[Reset]* button for approximately 3 seconds to


automatically adjust your calibration factor so that your Speed reading is the same as SOG.



- Alternatively, with the *[Calibration Factor]* page displayed use the *[Timer]* and *[Reset]* buttons to adjust the calibration factor until the displayed speed matches your estimated speed.

The default calibration factor is 1.00. The calibration factor can be set from 0.25 to 2.50.

- If SOG is available you can switch between the *[Calibration Factor]* and *[SOG]* pages by pressing the *[Timer]* and *[Reset]* buttons at the same time.



Note:


To exit the *[User Calibration]* menu, at any time, press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.

Nautical measured mile markers

When neither SOG data or any other reliable means of estimating Speed Through the Water (STW) is available, Nautical measured mile markers can be used to help calibrate Log speed. Nautical measured mile markers are identified by two pairs of posts or towers. The distance between each pair of markers is 1 nautical mile.

Each marker in a pair is separated by distance and elevation from its partner. The front marker is closer to the water and shorter than the marker behind it.


Markers — side view



- Front marker
- Rear marker

When the 2 markers appear vertically aligned your vessel is on the correct range line to begin a measured mile run.


Marker alignment (viewed from vessel)



- Vessel left of range line
- Vessel on range line
- Vessel right of range line

The vessel should already be at top speed and as the first pair of markers appear aligned a stopwatch should be started, when the vessel passes the second pair of aligned markers the stopwatch is stopped.

Measuring a nautical mile



1. Starting point (start stopwatch)
2. Measured mile
3. End point (stop stopwatch)
4. First pair of markers
5. Second pair of markers


To provide a more accurate reading the vessel should make between 4 to 6 runs in both directions to allow for tide and wind conditions. The average of the time taken over all runs should be used to calculate Log Speed.

The Log speed can then be worked out by taking the distance travelled (1 nautical mile) and dividing it by the average time taken to perform the run. The resulting calculation is your average speed in knots.

Selecting unit of measure for water temperature readings

During normal operation:


1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds, until *[USER CAL]* is displayed.



Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

2. Press the *[Speed]* button until the *[Water Temperature Units]* page is displayed (5 presses from *[USER CAL]*).




3. Use the *[Timer]* or *[Reset]* button to select the required unit of measurement for water temperature readings.
The units of measure available for temperature are:
 - °C (default) — degrees Celsius.
 - °F — degrees Fahrenheit.
4. You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the *[Speed]* button to cycle to the next setting in the menu.

Calibrating water temperature


You will need a suitable thermometer to measure the water temperature.

During normal operation:

1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds, until *[USER CAL]* is displayed.



1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds, until *[USER CAL]* is displayed.




Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.


Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

2. Press the *[Speed]* button until the *[Water Temperature Calibration]* page is displayed (6 presses from *[USER CAL]*).



2. Press the *[Speed]* button until *[TIMER]* is displayed (7 presses from *[USER CAL]*).




3. Use a suitable thermometer to measure the water temperature.
4. Use the *[Timer]* and *[Reset]* buttons to match the displayed water temperature to the water temperature measured by your thermometer.
5. You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.
6. Alternatively, you can press the *[Speed]* button to cycle to the next setting in the menu.

3. Use the *[Timer]* or *[Reset]* button to switch the timer buzzers *On* and *Off (default)*.
4. You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the *[Speed]* button to cycle to the next setting in the menu.

Enabling and disabling the timer buzzers

During normal operation:

Checking i50 Speed Software Version and Master / Repeater status



During normal operation:

1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 4 seconds, until *[VERSION]* is displayed.
2. Press the *[Speed]* button to display the *[Master/Repeater Status]* page.
The Master/Repeater status cannot be changed, if a transducer is connected to the display then it will be set as a Master, otherwise it will be set as a Repeater.
3. Press the *[Speed]* button again to begin the *[Speed Run Calibration]*.
4. To return to normal operation, at any time, press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.

Performing a Speed Run Calibration


The *[Speed Run Calibration]* involves carrying out 2 or more runs, over a measured distance, to enable a calibration factor to be determined. Each run consists of an outward and a return leg which minimizes the effect of tidal drift when the calibration factor is determined.

During normal operation:


Note:

This procedure is not required if the display's speed has been adjusted to SOG.


1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 4 seconds, until *[VERSION]* is displayed.
2. Press the *[Speed]* button until you reach the *[Speed Run Calibration]* page (2 presses from *[VERSION]*).




3. Press the *[Timer]* and *[Reset]* buttons at the same time.
The run length flashes.




4. Use the *[Timer]* and *[Reset]* buttons to adjust the run length to the required value.
Default value is 1.00, the run length can be set to any value between 0.25 and 2.5.
5. Press the *[Timer]* and *[Reset]* buttons at the same time to commence the *[Speed Run Calibration]*.
The *[Calibration Status]* page is displayed. The text at the top of the page alternates between *[START 1]* and the *[Calibration Factor]* currently applied.



6. Start the outward leg of the run and as you pass the start point, press the *[Trip]* button, so the page shows *[OUTWARD]* at the top. As the run proceeds, the displayed value will change.



7. At the end of the outward leg press *[Trip]* again.




The text *[RETURN]* will flash at the top of the page and the displayed distance freezes.

Note:

At this point the displayed distance may not be the same as the measured distance, due to errors introduced by tidal flow.


8. Turn your vessel round, start the return leg and as you do so, press the *[Trip]* button so *[RETURN]* stops flashing and the displayed value increments.



9. At the end of the return leg, press the *[Trip]* button.

At this point:

- The text *[START 2]* alternating with the new *[Calibration Factor]* displayed at the top of the page.
- The displayed distance freezes.




Note:

The displayed distance should be very close to the actual (measured) distance of the run.

10. If you are satisfied with the results of the first calibration run, press the *[Speed]* and *[Trip]* buttons at the same time to save the new *[Calibration Factor]* and exit the *[Speed Run Calibration]* menu.
11. If you want to carry out a second calibration run, press the *[Trip]* button.
12. Follow steps 5 to 7 above again to complete a second calibration run.
13. At the end of the return leg press the *[Trip]* button.

At this point:

- The text *[END]* alternating with the new *[Calibration Factor]* is displayed at the top of the page.
- The displayed distance freezes.




14. To exit the *[Speed Run Calibration]* at any time, press and hold the *[Speed]* and *[Trip]* buttons at the same time for 2 seconds.


Locking access to the User Calibration menu

During normal operation:

1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 14 seconds, until *[DEALER CAL]* is displayed.



2. Press the *[Timer]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.




3. Use the *[Timer]* or *[Reset]* button to switch access to the *[User Calibration]* menu either *On (default)* and *Off*.
Selecting *Off* disables access to the *[User Calibration]* menu.
4. You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the *[Speed]* button to cycle to the next setting in the menu.


Setting the response delay for speed readings

During normal operation:


1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 14 seconds, until *[DEALER CAL]* is displayed.



- Press the *[Timer]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



- Press the *[Speed]* button until the *[Speed Response]* page is displayed (1 press from the *[User Calibration Menu Access]* page).




- Use the *[Timer]* and *[Reset]* buttons to adjust the speed response to the required level.
The default level is 12. The levels available are 1 to 15 with level 1 being the slowest update rate and level 15 the quickest.
- You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Speed]* button to cycle to the next setting in the menu.


Setting the response delay for Velocity Made Good (VMG) readings

During normal operation:


- Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 14 seconds, until *[DEALER CAL]* is displayed.



- Press the *[Timer]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



- Press the *[Speed]* button until the *[VMG Response]* page is displayed (2 presses from the *[User Calibration Menu Access]* page).




- Use the *[Timer]* or *[Reset]* button to adjust the VMG response to the required level.
The default level is 12. The levels available are 1 to 15 with level 1 being the slowest update rate and level 15 the quickest.
- You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Speed]* button to cycle to the next setting in the menu.

Enabling and disabling Boat Show Mode


- *[Boat Show Mode]* can only be enabled on Repeater displays.
- *[Boat Show Mode]* is only suitable for demonstration purposes and should NOT be enabled whilst your vessel is in use.

During normal operation:


1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 14 seconds, until *[DEALER CAL]* is displayed.



2. Press the *[Timer]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



3. Press the *[Speed]* button until *[BOAT]* is displayed (3 presses from *[User Calibration Menu Access]* page).




4. Use the *[Timer]* or *[Reset]* button to switch the *[Boat Show Mode]* either *On* and *Off* (default).
Selecting *On* will put the display into *[Boat Show Mode]*.

5. You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.
6. Alternatively, you can press the *[Speed]* button to cycle to the next setting in the menu.


Resetting the display to factory defaults

During normal operation:


1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 14 seconds, until *[DEALER CAL]* is displayed.



2. Press the *[Timer]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.




3. Press the *[Speed]* button until *[RESET]* is displayed (4 presses from *[User Calibration Menu Access]* page).



4. To reset the display to factory default settings:
 - i. Use the *[Timer]* or *[Reset]* button to change the reset option to *Yes*.
 - ii. Press the *[Speed]* button to reset your display to factory default settings.
5. You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds.
6. Alternatively, you can press the *[Speed]* button to cycle to the next setting in the menu.

14.6 Using the speed pages

To cycle through the speed pages follow the steps below:



1. *[Current Speed]* page.
2. ⁽¹⁾ *[Maximum Speed]* page.
3. ⁽¹⁾ *[Average Speed]* page.
4. ⁽²⁾ *[VMG]* (wind) page.
5. ⁽³⁾ *[SOG]* page.


Note:

- (1) These pages are temporary pages and will revert back to the previous permanent page after 8 seconds of inactivity.
- (2) The VMG (wind) information is only available if your unit is part of a SeaTalk 1 or SeaTalk NG network which has a compatible wind instrument and transducer connected.
- (3) SOG information is only available if your unit is part of a SeaTalk 1 or SeaTalk NG network which has a suitable GPS connected.

1. Use the *[Speed]* button to cycle through the available speed pages.
2. From the *[Maximum Speed]* page or *[Average Speed]* page, press and hold the *[Reset]* button for approximately 3 seconds to reset the reading.

14.7 Using the log, trip and temperature pages

To cycle through the available log, trip and water temperature pages follow the steps below.




1. *[Current Speed]* page.
2. *[Log]* page.
3. *[Trip]* page.
4. *[Water temperature]* page.

During normal operation:

1. Use the *[Trip]* button to cycle through the available pages.
2. From the Trip page, press and hold the *[Reset]* button for approximately 3 seconds to reset the reading.

14.8 Using the timers

To cycle through and use the *[Race Timer]* pages and *[Stop Watch]* page follow the steps below.



During normal operation:


1. Press the *[Timer]* button to cycle through the available timers.
2. Press the *[Reset]* button to start the timer.
3. With the timer running, press the *[Reset]* button to pause the timer.
4. With the timer running, press and hold the *[Reset]* button for 1 second to reset the timer.

Note:

After the race timers have counted down to zero they will reverse (count upwards from zero).

Setting the race start timer

The race start timers can be set from 1 to 15 minutes.



With a *[Race Timer]* displayed:

1. Press the *[Timer]* and *[Reset]* buttons at the same time to adjust the race timer.
The set time will flash.
2. To change the race timer:
 - i. Use the *[Reset]* button to increase the *[Race Timer]* start value, or;
 - ii. Use the *[Timer]* button to decrease the *[Race Timer]* start value.
 - iii. Press the *[Timer]* and *[Reset]* buttons at the same time to confirm the new value.

Timer buzzer

The *[Timer buzzer]* is enabled or disabled during *[User Calibration]*. When using a *[Race Timer]* with the *[Timer buzzer]* enabled, the buzzer will:

- Short double-beep every minute.
- Long beep x3 at the start of the last 30 seconds.

- Short beep once for each of the last 10 seconds.
- Long beep at zero.

14.9 Illumination

Adjusting the backlight level

The backlighting level can be accessed using the *[Power]* button.

During normal operation:

1. Press and hold the *[Power]* button for approximately 2 seconds until *[LAMPS]* is displayed.
2. Use the *[Up]* button to increase the backlight setting, or,
3. Use the *[Down]* button to decrease the backlight setting.

The backlight level can be adjusted from level 1 to level 9 or switched *Off (default)*.

Note:

The backlight page will time-out after 8 seconds of inactivity.

Adjusting the contrast

During normal operation:

1. Press and hold the *[Power]* button for approximately 4 seconds until *[CONTRAST]* is displayed.
2. Use the *[Power]* button to cycle through the available contrast levels.

The contrast level can be adjusted from level 0 (default) to 3.

Note:

The contrast page will time-out after 8 seconds of inactivity.

Group illumination

Group illumination is used to synchronize and control the backlighting level of multiple units assigned to the same group.

The unit can participate in shared illumination via a SeaTalk 1 network or group illumination via a SeaTalk NG network.

When connected on a SeaTalk 1 network all compatible units will share their backlight level (when 1 unit's backlighting level is adjusted all other units backlight level will also change).

When connected on a SeaTalk NG network the unit can participate in group illumination and be assigned to a group of units which will share their backlighting levels. Available groups are as follows:

- *OFF (default)* — Group illumination is switched off
- *HL1* — Helm 1
- *HL2* — Helm 2
- *CPt* — Cockpit
- *FLY* — Flybridge
- *NST* — Mast
- *GP1* to *GP5* — User defined groups

When assigned to a group, when the backlighting of 1 unit is adjusted the backlighting level of all units assigned to the same group will also change.

Assigning the i50 Speed to a group

To assign the i50 Speed as part of a group so that it can participate in group illumination follow the steps below.

During normal operation:

1. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for 6 seconds, until the *[Group illumination]* page is displayed.
[GROUP CAL] is displayed on-screen.

Note:

The *[Group illumination]* entry page is a temporary page and will time-out to the previous page after 8 seconds.

2. Press the *[Speed]* button to display the *[Groups]* page.
3. Press the *[Timer]* and *[Reset]* buttons at the same time to enable selection of a group.
The group setting will flash.
4. Use the *[Reset]* button to cycle upwards through the list of available groups.
5. Use the *[Timer]* button to cycle back down through the list.

6. Press the *[Timer]* and *[Reset]* buttons at the same time to assign the display to the selected group.
The group setting will stop flashing.
7. Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 2 seconds to return to normal operation.

CHAPTER 15: I50 TRIDATA

CHAPTER CONTENTS

- 15.1 i50 Tridata operation — page 91
- 15.2 i50 Tridata controls — page 92
- 15.3 Switching on the display — page 92
- 15.4 Switching off the display — page 92
- 15.5 Data master — page 92
- 15.6 Calibration — page 93
- 15.7 Using Tridata depth pages — page 107
- 15.8 Using Tridata speed pages — page 107
- 15.9 Using Tridata trip, log, temp and timer pages — page 108
- 15.10 Using the timers — page 109
- 15.11 Alarms — page 109
- 15.12 Illumination — page 111

15.1 i50 Tridata operation

When connected to the relevant transducer(s) your i50 Tridata instrument:

- Provides depth information in either feet (FT) or metres (M).
- Enables you to define alarm thresholds for shallow alarm, deep alarm, shallow anchor alarm and deep anchor alarm.
- Provides speed information (current, maximum and average), in either knots (KTS), miles per hour (MPH) or kilometers per hour (KPH).
- Velocity made good (VMG) information, VMG is only available when connected to a SeaTalk 1 or SeaTalk NG network which also contains a compatible wind transducer.
- Provides log and trip information. These are given in either nautical miles (NM), statute miles (M) or kilometers (KM).
- Provides water temperature information. This is given in either degrees celsius (°C) or degrees fahrenheit (°F).
- Provides count up and race start timer functions.

Note:


Depth information is obtained from the depth transducer connected to the unit. However, when the instrument is connected to a SeaTalk 1 network, which contains a compatible sonar module (fishfinder) the depth information is provided by the sonar module whilst it is switched on.

It should be noted that:

- The required units of measurement are set during *[User calibration]*.
- Up / Down depth-trend arrows are displayed, if the seabed is rising or falling at a significant rate.
- The log screen shows the total distance covered by the vessel since the unit was fitted.
- Maximum speed, average speed and trip reading are reset to zero at power up.
- If for any reason depth information is lost, the depth title will flash and the displayed value will be the last known depth reading.

i50 Tridata display layout

The i50 Tridata display is divided into 3 separate areas, each of which displays a separate type of information, as shown below.



Description

- 1 Depth information.
- 2 Speed information.
- 3 Trip, log, water temperature and timer.

15.2 i50 Tridata controls



Description

- 1 *[Speed]*— Select to access Speed and VMG information.
- 2 *[Trip / Down]*— Select to access log, trip and water temperature information. Use to move down through menu options or to decrease numeric values.
- 3 *[Depth / Power]*— Select to access Depth information, adjust backlight, adjust contrast and power the display On and Off.
- 4 *[Reset / Up]*— Select and hold down for 3 seconds to reset data to current values. Use to move up through menu options or to increase numeric values.

15.3 Switching on the display

The display will automatically switch on when power is applied to the SeaTalk NG backbone, unless the display has previously been switched off using the *[Power]* button. If the *[Power]* button has been used to switch off the display then it must be used to switch the display back on again.

With the display powered but switched off:

1. Press and hold the *[Power]* button until the screen turns on (approximately 2 seconds).

15.4 Switching off the display

The display can be switched off using the *[Power]* button.

1. Press and hold the *[Power]* button until the count down timer reaches zero and the screen turns off.

Note:


When switched off, the display may still draw a small amount of power from the battery, if this is a concern unplug the SeaTalk NG power supply or switch off at the breaker.

15.5 Data master

Where a system contains more than one unit capable of displaying a data type, the unit physically connected to the transducer must be set as the data *master* and any other units set as a *repeater*.

Changing i50 Tridata Master / Repeater status

Displays that have a transducer physically attached to them are automatically set as Data Masters. You can set your display to show Depth readings from a different source.



During normal operation:

1. Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 4 seconds, until *[UEr]* is displayed.
2. Press the *[Depth]* button to display the *[Master/Repeater Status]* page.

Default: Master (transducer connected) or Repeater (No transducer connected).

3. Press the *[Trip]* and *[Reset]* buttons at the same time. The status will start to flash.
4. Use the *[Trip]* or *[Reset]* button to switch the status between *Master* or *Repeater*.
5. Press the *[Trip]* and *[Reset]* buttons at the same time to confirm the status.
6. Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds to return to normal operation.
7. Power off the display by pressing and holding the *[Power]* button until the screen turns off.
8. Power the display back on by pressing and holding the *[Power]* button until the screen turns on (approximately 2 seconds).
9. Check the display's status by repeating steps 1 and 2 above.

15.6 Calibration

Before first use the unit must be calibrated to ensure optimum performance. The calibration settings are grouped into 3 categories: **User Calibration**, **Intermediate Calibration** and **Dealer Calibration**.

Access to the *[User Calibration]* menu can be locked from the *[Dealer Calibration]* menu.


Tridata calibration pages

The following calibration procedures can be accessed from the calibration menus referenced below.

User Calibration	Intermediate Calibration	Dealer Calibration
<i>[Depth units]</i>	<i>[Software Version]</i>	<i>[User Calibration Menu Access]</i>
⁽¹⁾ <i>[Depth Offset]</i>	<i>[Master/Repeater Status]</i>	<i>[Speed Data Source]</i>
<i>[Speed units]</i>	<i>[Speed Run Calibration]</i>	<i>[Display Response — Speed]</i>

User Calibration	Intermediate Calibration	Dealer Calibration
[Speed Resolution]		[Display Response — Depth]
[Log units]		[Boat Show Mode]
(1) [Calibration Factor / SOG]		[Factory Reset]
[Water Temperature units]		
[Water Temperature Calibration]		
[Timer buzzer]		

2. Press the [Depth] button until the [Depth Units] page is displayed (1 press from [CAL]).



3. Use the [Trip] and [Reset] buttons to select the required units of measurement for depth readings.

The units of measure available for depth readings are:

- FEET (default)
- METRES

4. You can exit the [User Calibration] menu, at any time by pressing and holding the [Depth] and [Speed] buttons at the same time for approximately 2 seconds.

5. Alternatively, you can press the [Depth] button to cycle to the next setting in the menu.


Note:

(1) Settings are only available when the instrument status is set to *Master*.

Selecting the unit of measure for depth readings

During normal operation:

1. Press and hold down the [Depth] and [Speed] buttons at the same time for approximately 2 seconds, until [CAL] is displayed.




Depth Offset

Depths are measured from the transducer face to the bottom (e.g.: seabed). An offset value can be applied to the depth data so that the displayed depth reading represents the depth reading taken from either the keel (negative offset) or the waterline (positive offset).

Before attempting to set a waterline or keel offset, find out the vertical distance between the transducer and either the waterline or the bottom of your vessel's keel, as appropriate. Then set the distance as the depth offset value.

Note:

The [User Calibration] menu will time-out after 8 seconds of inactivity.




1. *[Waterline offset]*— Values greater than zero (Positive values) represent a waterline offset
2. *[Transducer]*— Zero offset represents the depth from the transducer's location
3. *[Keel offset]*— Values less than zero (Negative values) represent a keel offset

Applying a Depth Offset

During normal operation:


1. Press and hold down the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds, until *[CAL]* is displayed.



Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

2. Press the *[Depth]* button until the *[Depth Offset]* page is displayed (2 presses from *[CAL]*).




3. Use the *[Trip]* and *[Reset]* buttons to adjust the depth offset to the required value.
4. You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Selecting the unit of measure for speed readings

During normal operation:


1. Press and hold down the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds, until *[CAL]* is displayed.



Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

- Press the *[Speed]* button until the *[Speed Units]* page is displayed (1 press from *[CAL]*).



- Use the *[Trip]* or *[Reset]* button to select the required unit of measurement for speed readings.

The units of measure available for speed readings are:


- *KTS* — *Knots (default)*
- *MPH* — *Miles Per Hour*
- *KMH* — *Kilometers Per Hour*

- You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Selecting a resolution for speed readings

During normal operation:


- Press and hold down the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds, until *[CAL]* is displayed.



Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

- Press the *[Speed]* button until the *[Speed Resolution]* page is displayed (2 presses from *[CAL]*).



- Use the *[Trip]* or *[Reset]* button to select the required resolution for speed readings.


The resolutions available are *0.01 (default)* and *0.1*.

- You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Selecting the unit of measure for log readings


During normal operation:

- Press and hold down the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds, until *[CAL]* is displayed.



Note: The [User Calibration] menu will time-out after 8 seconds of inactivity.

2. Press the [Speed] button until the [Log Units] page is displayed (3 presses from [CAL]).



3. Use the [Trip] or [Reset] button to select the required unit of measurement for log readings.
 - KM (default) — Kilometers
 - SM — Statute Miles
 - NM — Nautical Miles
4. You can exit the [User Calibration] menu, at any time by pressing and holding the [Depth] and [Speed] buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the [Depth] button to cycle to the next setting in the menu.

1 point speed calibration

The display's speed readings can be calibrated using a quick, 1 point calibration process, in most situations this is all that will be required to calibrate your speed readings.


Prerequisites:

- For best results SOG data should be available, or an alternative method of estimating vessel speed must be used; e.g. vessel speed can be estimated using nautical measured mile markers or similar landmarks of a known distance apart. For more information, refer to: [p.98 — Nautical Measured Mile Markers](#)
- You will need to be underway, with sufficient space to maneuver unhindered.

- In order to achieve accurate results, water conditions must be calm with zero tide and zero current.


During normal operation:

1. Steer your vessel on a steady course at a constant typical speed.
2. Press and hold down the [Depth] and [Speed] buttons at the same time for approximately 2 seconds, until [CAL] is displayed.




Note: The [User Calibration] menu will time-out after 8 seconds of inactivity.


3. Press the [Speed] button until one of the [Current Speed] pages is displayed (4 presses from [CAL]).
If SOG data is available over SeaTalk NG then the [SOG] page is displayed, if SOG data is not available then the [Calibration Factor] page is displayed.



- If the *[SOG]* page is displayed and the water conditions are acceptable, press and hold the *[Reset]* button for approximately 3 seconds to automatically adjust your calibration factor so that your Speed reading is the same as SOG.



- Alternatively, with the *[Calibration Factor]* page displayed use the *[Trip]* and *[Reset]* buttons to adjust the calibration factor until the displayed speed matches your estimated speed. The default calibration factor is 1.00. The calibration factor can be set from 0.25 to 2.50.
- If SOG is available you can switch between the *[Calibration Factor]* and *[SOG]* pages by pressing the *[Trip]* and *[Reset]* buttons at the same time.



Note:


To exit the *[User Calibration]* menu at any time, press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.

Nautical measured mile markers

When neither SOG data or any other reliable means of estimating Speed Through the Water (STW) is available, Nautical measured mile markers can be used to help calibrate Log speed. Nautical measured mile markers are identified by two pairs of posts or towers. The distance between each pair of markers is 1 nautical mile.

Each marker in a pair is separated by distance and elevation from its partner. The front marker is closer to the water and shorter than the marker behind it.


Markers — side view



- Front marker
- Rear marker

When the 2 markers appear vertically aligned your vessel is on the correct range line to begin a measured mile run.


Marker alignment (viewed from vessel)



- Vessel left of range line
- Vessel on range line
- Vessel right of range line

The vessel should already be at top speed and as the first pair of markers appear aligned a stopwatch should be started, when the vessel passes the second pair of aligned markers the stopwatch is stopped.

Measuring a nautical mile



1. Starting point (start stopwatch)
2. Measured mile
3. End point (stop stopwatch)
4. First pair of markers
5. Second pair of markers


To provide a more accurate reading the vessel should make between 4 to 6 runs in both directions to allow for tide and wind conditions. The average of the time taken over all runs should be used to calculate Log Speed.

The Log speed can then be worked out by taking the distance travelled (1 nautical mile) and dividing it by the average time taken to perform the run. The resulting calculation is your average speed in knots.

Selecting unit of measure for water temperature readings

During normal operation:


1. Press and hold down the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds, until *[CAL]* is displayed.



Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

2. Press the *[Speed]* button until the *[Water Temperature Units]* page is displayed (5 presses from *[CAL]*).




3. Use the *[Trip]* or *[Reset]* button to select the required unit of measurement for water temperature readings.
The units of measure available for temperature are:
 - °C (*default*) — degrees Celsius
 - °F — degrees Fahrenheit
4. You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the *[Speed]* or the *[Depth]* button to cycle to the next setting in the menu.

Calibrating water temperature

You will need a suitable thermometer to measure the water temperature.

During normal operation:


1. Press and hold down the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds, until *[CAL]* is displayed.



Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

2. Press the *[Speed]* button until the *[Water Temperature Calibration]* page is displayed (6 presses from *[CAL]*).




3. Use a suitable thermometer to measure the water temperature.
4. Use the *[Trip]* and *[Reset]* buttons to match the displayed water temperature to the water temperature measured by your thermometer.
5. You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
6. Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Enabling and disabling timer buzzers

During normal operation:


1. Press and hold down the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds, until *[CAL]* is displayed.



Note:

The *[User Calibration]* menu will time-out after 8 seconds of inactivity.

2. Press the *[Speed]* button until the *[Timer buzzer]* page is displayed (7 presses from *[CAL]*).



3. Use the *[Trip]* or *[Reset]* button to switch the timer's buzzer *On* and *Off* (default).
4. You can exit the *[User Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
5. Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Checking the software version

To check the software version of your display follow the steps below.

During normal operation:

1. Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 4 seconds, until *[Version]* is displayed.

Performing Speed Run Calibration


The *[Speed Run Calibration]* involves carrying out 2 or more runs, over a measured distance, to enable a calibration factor to be determined. Each run consists of an outward and a return leg which minimizes the effect of tidal drift when the calibration factor is determined.

Note:


This procedure is not required if current speed is set to SOG.

During normal operation:


1. Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 4 seconds, until *[UEr]* is displayed.
2. Press the *[Depth]* button until you reach the *[Calibration Run]* page (2 presses from the *[Software Version]* page).




3. Press the *[Trip]* and *[Reset]* buttons at the same time. The run length will flash.



4. Use the *[Trip]* and *[Reset]* buttons to adjust the run length to the required value. The default value is *1.00 (default)* the setting can be adjusted from *0.25* to *2.50*.
5. Press the *[Trip]* and *[Reset]* buttons at the same time to commence the *[Speed Run Calibration]*. The text in the bottom section of the screen alternates between *[Strt 1]* and the current *[Calibration Factor]*.




6. Start the outward leg of the calibration run and as you pass the start point, press the *[Speed]* button, so the page shows *[Out]* at the bottom of the screen.



As the calibration run proceeds, the displayed value will change.

7. At the end of the outward leg press the *[Speed]* button again.




The text *[rEtrn]* will flash at the bottom of the screen and the displayed distance freezes.

Note:

At this point the displayed distance may not be the same as the measured distance, due to errors introduced by tidal flow.


8. Turn your vessel round, start the return leg and as you do so, press the *[Speed]* button so that *[rEtrn]* stops flashing and the displayed value increments.



9. At the end of the return leg, press the *[Speed]* button.

At this point:

- The text *[START 2]* alternating with the new *[Calibration Factor]* is displayed at the top of the page.
- The displayed distance freezes.




Note:

The displayed distance should be very close to the actual (measured) distance of the run.

10. If you are satisfied with the results of the first calibration run, press the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds to save the new *[Calibration Factor]*, exit speed calibration and return to normal operation.
11. If you want to carry out a second run, press the *[Speed]* button.
12. Follow steps 5 to 7 above again to complete a second calibration run.
13. At the end of the return leg press the *[Speed]* button

At this point:

- The text *[END]* alternating with the new *[Calibration Factor]* is displayed at the top of the page.
- The displayed distance freezes.




14. To exit the *[Speed Run Calibration]*, at any time, press and hold the *[Depth]* and *[Speed]* buttons for approximately 4 seconds.

Locking access to the User Calibration menu


From the *[Dealer Calibration]* menu you can lock access to the *[User Calibration]* menu.

During normal operation:

1. Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 14 seconds, until the *[dlr CAL]* is displayed.



2. Press the *[Trip]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



3. Use the *[Trip]* or *[Reset]* button to switch access to the *[User Calibration Menu]* On (default) and Off. Selecting *Off* disables access to the *[User Calibration Menu]*.

4. You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.


5. Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Setting speed to SOG


Your display can be configured to use SOG data, if available, as the source for speed data instead of a speed transducer.

During normal operation:


1. Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 14 seconds, until the *[dlr CAL]* is displayed.



- Press the *[Trip]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



- Press the *[Depth]* button until the *[Speed Source]* page is displayed (1 press from the *[User Calibration Menu Access]* page).




- Use the *[Trip]* or *[Reset]* button to switch the speed data source *On* and *Off* (default).
Selecting *On* will display SOG reading instead of speed transducer readings.
- You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.


Setting the response delay for speed readings

During normal operation:


- Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 14 seconds, until the *[dlr CAL]* is displayed.



- Press the *[Trip]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



- Press the *[Depth]* button until the *[Speed Response]* page is displayed (1 press from the *[User Calibration Menu Access]* page).




- Use the *[Trip]* and *[Reset]* buttons to adjust the speed response to the required level.
The default level is 12. The levels available are 1 to 15 with level 1 being the slowest update rate and level 15 the quickest.
- You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.

- Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.


Setting the response delay for depth readings

During normal operation:


- Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 14 seconds, until the *[dlr CAL]* is displayed.



- Press the *[Trip]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



- Press the *[Depth]* button until the *[Depth Response]* page is displayed (3 presses from the *[User Calibration Menu Access]* page).



- Use the *[Trip]* and *[Reset]* buttons to adjust the depth response to the required level.

The default level is 12. The levels available are 1 to 15 with level 1 being the slowest update rate and level 15 the quickest.


- You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
- Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

Enabling and disabling Boat Show Mode


- [Boat Show Mode]* can only be enabled on Repeater displays.
- [Boat Show Mode]* is only suitable for demonstration purposes and should NOT be enabled whilst your vessel is in use.

During normal operation:


- Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 14 seconds, until the *[dlr CAL]* is displayed.



- Press the *[Trip]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.



3. Press the *[Depth]* button until the *[Boat Show Mode]* page is displayed (4 presses from *[User Calibration Menu Access]* page).




4. Use the *[Trip]* or *[Reset]* button to switch boat show mode *On* and *Off* (default).
5. You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
6. Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.


Resetting the display to factory defaults

During normal operation:


1. Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 14 seconds, until the *[dlr CAL]* is displayed.



2. Press the *[Trip]* and *[Reset]* buttons at the same time to display the *[User Calibration Menu Access]* page.




3. Press the *[Depth]* button until *[rESEt]* is displayed (5 presses from *[User Calibration Menu Access]* page).



4. To reset the display to factory default settings:
 - i. Use the *[Trip]* or *[Reset]* button to change the reset option to *Yes*.
 - ii. Press the *[Depth]* button to reset your display to factory default settings.
5. After a reset it is recommended that you check the data master status of the display to ensure it is set correctly. For more information, refer to: [p.92 – Data master](#)
6. You can exit the *[Dealer Calibration]* menu, at any time by pressing and holding the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds.
7. Alternatively, you can press the *[Depth]* button to cycle to the next setting in the menu.

15.7 Using Tridata depth pages

To cycle through the depth pages follow the steps below.



1. Use the *[Depth]* button to cycle through the available depth pages. Available depth pages are:
 - *[Current depth]*
 - *[Shallow depth alarm]*
 - *[Deep depth alarm]*
 - *[Shallow anchor alarm]*
 - *[Deep anchor alarm]*


Note:

Alarm pages are temporary pages will time-out after 8 seconds and revert to the *[Current depth]* page.

To enable / disable alarms or to adjust alarm thresholds, refer to the following section: [p.109 – Alarms](#)

15.8 Using Tridata speed pages

To cycle through the speed pages follow the steps below.



1. *[Current Speed]* page.
2. ⁽¹⁾ *[Maximum Speed]* page.
3. ⁽¹⁾ *[Average Speed]* page.
4. ⁽²⁾ *[VMG]* page.


Note:

- (1) These pages are temporary pages and will revert back to the previous permanent page after 8 seconds of inactivity.
- (2) The VMG information is only available if your unit is part of a SeaTalk 1 or SeaTalk NG network which has a compatible wind instrument and transducer connected.

1. Use the *[Speed]* button to cycle through the available speed pages.
2. From the *[Maximum Speed]* page or *[Average Speed]* page, press and hold the *[Reset]* button for approximately 3 seconds to reset the reading.

15.9 Using Tridata trip, log, temp and timer pages

To cycle through the trip, log, water temperature and timer pages follow the steps below.



1. Press the *[Trip]* button to cycle through the *[Trip]*, *[Log]*, *[Water temperature]* and *[Timer]* pages.

15.10 Using the timers

To cycle through and use the *[Race Timer]* pages and *[Stop Watch]* page follow the steps listed below.

With a timer page displayed:


1. Press the *[Reset]* button to start the timer.
2. With the timer running, press the *[Reset]* button to pause the timer.
3. With the timer running, press and hold the *[Reset]* button for approximately 1 second to reset the timer.

Note:

After the race timers have counted down to zero they will reverse (count upwards from zero).

Setting the race timer

There are 2 race (count-down) timers. The race timers can be set from 1 to 15 minutes.



With a *[Race Timer]* displayed:

1. Press the *[Trip]* and *[Reset]* buttons at the same time to edit the timer.
2. Use the *[Reset]* button to increment the race timer start value, or
3. Use the *[Trip]* button to decrease the race timer start value.
4. Press the *[Trip]* and *[Reset]* buttons at the same time to confirm the new value.

Note:

After a *[Race Timer]* has counted down to zero it will then start to count up.

Timer buzzer

The *[Timer buzzer]* is enabled or disabled during *[User Calibration]*. When using a *[Race Timer]* with the *[Timer buzzer]* enabled, the buzzer will:

- Short double-beep every minute.
- Long beep x3 at the start of the last 30 seconds.
- Short beep once for each of the last 10 seconds.
- Long beep at zero.

15.11 Alarms

Alarms alert you to a situation or hazard requiring your attention.

You can set up alarms to alert you to certain conditions.

Alarms are raised by system functions, and also external equipment connected to your display.

When an alarm event occurs an audible and visual alarm is activated which indicates the alarm state.

Alarm thresholds can be configured from the relevant alarm page / menu.

Instrument alarms

The alarms available for the i50 Depth and i50 Tridata are listed below.

- *[Shallow depth alarm]*
- *[Deep depth alarm]*
- *[Shallow anchor alarm]*
- *[Deep anchor alarm]*

Alarm indications

An alarm event is indicated by both audible and visual warnings.

Shallow alarm



Deep alarm



Shallow anchor alarm



Deep anchor alarm



Alarms are sounded when the set alarm threshold value is crossed. Alarms will sound until silenced.

Silencing alarms

1. Press any button to silence an active alarm.

Enabling / Disabling alarms


Alarms can be enabled or disabled at any time.

With the relevant alarm page displayed:

1. Press and hold the *[Reset]* button for 1 second to switch the alarm *on* or *off*.

Setting alarm thresholds

You can adjust the threshold at which alarms are triggered by following the steps below.



With the relevant alarm page displayed:

1. Press the *[Trip]* and *[Reset]* buttons at the same time. The current alarm threshold will start to flash.
2. Use the *[Reset]* button to increase the alarm threshold.
3. Use the *[Trip]* button to decrease the alarm threshold.
4. The alarm threshold page will time-out after approximately 6 seconds of inactivity, automatically saving the new alarm threshold.

Shallow alarm lock

The *[Shallow Alarm Lock]* feature is designed to prevent unintentional adjustment of the shallow alarm threshold value.

When setting the shallow alarm threshold:

1. Press and hold the *[Reset]* button for 3 seconds to lock the shallow alarm threshold value.
2. The *[Shallow Alarm Lock]* can be turned off again by pressing and holding the *[Reset]* button when adjusting the threshold.

15.12 Illumination

Adjusting the backlight level

The backlighting level can be accessed using the *[Power]* button.

During normal operation:

1. Press and hold the *[Power]* button for approximately 2 seconds to display the *[Backlight]* page.

[L] is displayed on-screen and the current backlight level.

2. Use the *[Up]* button to increase the backlight setting to the required level.
3. Use the *[Down]* button to decrease the backlight setting to the required level.

The backlight level can be adjusted from level 1 to 9 or switched *Off (default)*.

Note:

The backlight page will time-out after 8 seconds of inactivity.

Adjusting the contrast

The contrast level can be accessed using the *[Power]* button.

During normal operation:

1. Press and hold the *[Power]* button for approximately 4 seconds until *[CONtrAST]* is displayed.
2. Use the *[Power]* button to cycle through the available contrast levels.

The contrast level can be adjusted from level *0 (default)* to *3*.

Note:

The contrast page will time-out after 8 seconds of inactivity.

Group illumination

Group illumination is used to synchronize and control the backlighting level of multiple units assigned to the same group.

The unit can participate in shared illumination via a SeaTalk 1 network or group illumination via a SeaTalk NG network.

When connected on a SeaTalk 1 network all compatible units will share their backlight level (when 1 unit's backlighting level is adjusted all other units backlight level will also change).

When connected on a SeaTalk NG network the unit can participate in group illumination and be assigned to a group of units which will share their backlighting levels. Available groups are as follows:

- *OFF (default)* — Group illumination is switched off

- *HL1* — Helm 1
- *HL2* — Helm 2
- *CPt* — Cockpit
- *FLY* — Flybridge
- *NST* — Mast
- *GP1* to *GP5* — User defined groups

When assigned to a group, when the backlighting of 1 unit is adjusted the backlighting level of all units assigned to the same group will also change.

Assigning the i50 Tridata to a group

To assign the i50 Tridata as part of a group so that it can participate in group illumination follow the steps below.

During normal operation:

1. Press and hold the *[Depth]* and *[Speed]* buttons at the same time for 6 seconds, until the *[Group illumination]* page is displayed.
[GROUP CAL] is displayed on-screen.

Note:

The *[Group illumination]* entry page is a temporary page and will time-out to the previous page after 8 seconds.

2. Press the *[Depth]* button to display the *[Groups]* page.
3. Press the *[Trip]* and *[Reset]* buttons at the same time to enable selection of a group.
The group setting will flash.
4. Use the *[Reset]* button to cycle upwards through the list of available groups.
5. Use the *[Trip]* button to cycle back down through the list.
6. Press the *[Trip]* and *[Reset]* buttons at the same time to assign the display to the selected group.
The group setting will stop flashing.
7. Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 2 seconds to return to normal operation.

CHAPTER 16: MAINTAINING YOUR DISPLAY

CHAPTER CONTENTS

- 16.1 Service and maintenance — page 114
- 16.2 Routine equipment checks — page 114
- 16.3 Cleaning the display case — page 114
- 16.4 Cleaning the display screen — page 114

16.1 Service and maintenance

This product contains no user serviceable components. Please refer all maintenance and repair to authorized Raymarine dealers. Unauthorized repair may affect your warranty.

Caution: Condensation

Certain atmospheric conditions may cause a small amount of condensation to form on the unit's window. This will not damage the unit and will clear after the unit has been switched on for a short period.

16.2 Routine equipment checks

It is recommended that you perform the following routine checks, on a regular basis, to ensure the correct and reliable operation of your equipment:

- Examine all cables for signs of damage or wear and tear.
- Check that all cables are securely connected.

16.3 Cleaning the display case

The display is a sealed unit and does not require regular cleaning. If it is necessary to clean the display, follow this basic procedure:

1. Switch off the power to the display.
2. Wipe the case with a clean, lint-free cloth.
3. If necessary, use a mild detergent to remove grease marks.

16.4 Cleaning the display screen

A coating is applied to the display screen. This makes it water repellent, and prevents glare. To avoid damaging this coating, follow this procedure:

1. Switch off the power to the display.
2. Rinse the screen with fresh water to remove all dirt particles and salt deposits.

3. Allow the screen to dry naturally.
4. If any smears remain, very gently wipe the screen with a clean microfibre cleaning cloth.

Caution: Product cleaning

When cleaning products:

- Switch off power supply.
- Use a clean damp cloth to wipe clean.
- Do NOT use: abrasive, acidic, ammonia, solvent or other chemical based cleaning products.
- Do NOT use a jet wash.

CHAPTER 17: TROUBLESHOOTING

CHAPTER CONTENTS

- 17.1 Troubleshooting — page 116
- 17.2 Instrument troubleshooting — page 116
- 17.3 Power up troubleshooting — page 117
- 17.4 Miscellaneous troubleshooting — page 118

17.1 Troubleshooting

The troubleshooting section provides possible causes and the corrective action required for common problems that are associated with the installation and operation of your product.

Before packing and shipping, all Raymarine products are subjected to comprehensive testing and quality assurance programs. If you do experience problems with your product, this section will help you to diagnose and correct problems to restore normal operation.

If after referring to this section you are still having problems with your product, please refer to the *Technical support* section of this manual for useful links and Raymarine technical support contact details.

17.2 Instrument troubleshooting

Information not transferred between instruments:

Possible causes	Possible solutions
Cabling / connector fault:	<ul style="list-style-type: none">• Check the security and condition of all SeaTalk 1 / SeaTalk NG connections between units.• Attempt to isolate any faulty units by disconnecting the units one by one.

Daisy-chained SeaTalk 1 / SeaTalk NG units not working:

Possible causes	Possible solutions
Cabling / connector fault:	<ul style="list-style-type: none">• Check the security and condition of all SeaTalk 1 / SeaTalk NG connections between functioning and non-functioning units.

[LAST] flashing or dashes displayed continuously (depth greater than 3 feet):

Possible causes	Possible solutions
Transducer cable or connector fault:	<ul style="list-style-type: none">• Check the security and condition of any transducer connections

[LAST] flashes when under way:

Possible causes	Possible solutions
Aerated water due to vessel wakes, propeller wash, etc:	<ul style="list-style-type: none">• Ensure reading stabilizes when clear of disturbed water.

17.3 Power up troubleshooting

Product does not turn on or keeps turning off:

Possible causes	Possible solutions
Blown fuse / tripped breaker:	<ol style="list-style-type: none"> 1. Check condition of relevant fuses and breakers and connections, replace if necessary. (Refer to the <i>Technical Specification</i> section of your product's installation instructions for fuse ratings.) 2. If fuse keeps blowing check for cable damage, broken connector pins or incorrect wiring.
Poor / damaged / insecure power supply cable / connections:	<ol style="list-style-type: none"> 1. Check that the power cable connector is correctly orientated and fully inserted into the display connector and locked in position. 2. Check the power supply cable and connectors for signs of damage or corrosion, and replace if necessary. 3. With the display turned on, try flexing the power cable near to the display connector to see if this causes the unit to restart or lose power. Replace if necessary. 4. Check the vessel's battery voltage and the condition of the battery terminals and power supply cables, ensuring connections are secure, clean and free from corrosion. Replace if necessary. 5. With the product under load, using a multi-meter, check for high voltage drop across all connectors / fuses etc, and replace if necessary.
Incorrect power connection:	The power supply may be wired incorrectly, ensure the installation instructions have been followed.

Product will not start up (restart loop):

Possible causes	Possible solutions
Power supply and connection:	See possible solutions from the table above, entitled 'Product does not turn on or keeps turning off'.
Software corruption:	<ol style="list-style-type: none"> 1. In the unlikely event that the product's software has become corrupted, try downloading and installing the latest software from the Raymarine website. 2. On display products, as a last resort, attempt to perform a 'Power on Reset'. Be aware that this will delete all settings / presets and user data (such as waypoints and tracks), and revert the unit back to factory defaults.

17.4 Miscellaneous troubleshooting

Miscellaneous problems and their possible causes and solutions are described here.

Display behaves erratically (frequent unexpected resets / system crashes, or other erratic behavior):

Possible causes	Possible solutions
Intermittent problem with power to the display.	<ul style="list-style-type: none">• Check relevant fuses and breakers.• Check that the power supply cable is sound and that all connections are tight and free from corrosion.• Check that the power source is of the correct voltage and sufficient current.
Software mismatch on system (upgrade required).	Go to https://bit.ly/rym-software for the latest software downloads.
Corrupt data / other unknown issue.	Perform a factory reset.

Important:

This will result in the loss of any settings and data (such as waypoints) stored on the product. Save any important data to a memory card before resetting.

CHAPTER 18: TECHNICAL SUPPORT

CHAPTER CONTENTS

- 18.1 Raymarine technical support and servicing — page 120
- 18.2 Checking the software version — page 121
- 18.3 Learning resources — page 121

18.1 Raymarine technical support and servicing

Raymarine provides a comprehensive product support service, as well as warranty, service, and repairs. You can access these services through the Raymarine website, telephone, and e-mail.

Product information

If you need to request service or support, please have the following information to hand:

- Product name.
- Product identity.
- Serial number.
- Software application version.
- System diagrams.

You can obtain this product information using diagnostic pages of the connected display.

Servicing and warranty

Raymarine offers dedicated service departments for warranty, service, and repairs.

Don't forget to visit the Raymarine website to register your product for extended warranty benefits: <https://www.raymarine.com/en-us/support/product-registration>

United Kingdom (UK), EMEA, and Asia Pacific:

- E-Mail: emea.service@raymarine.com
- Tel: +44 (0)1329 246 932

United States (US):

- E-Mail: rm-usrepair@flir.com
- Tel: +1 (603) 324 7900

Web support

Please visit the "Support" area of the Raymarine website for:

- **Manuals and Documents** — <http://www.raymarine.com/manuals>
- **Technical support forum** — <https://raymarine.custhelp.com/app/home>
- **Software updates** — <http://www.raymarine.com/software>

Worldwide support

United Kingdom (UK), EMEA, and Asia Pacific:

- Help desk: <https://raymarine.custhelp.com/app/home>
- Tel: +44 (0)1329 246 777

United States (US):

- Help desk: <https://raymarine.custhelp.com/app/home>
- Tel: +1 (603) 324 7900 (Toll-free: +800 539 5539)

Australia and New Zealand (Raymarine subsidiary):

- E-Mail: aus.support@raymarine.com
- Tel: +61 2 8977 0300

France (Raymarine subsidiary):

- E-Mail: support.fr@raymarine.com
- Tel: +33 (0)1 46 49 72 30

Germany (Raymarine subsidiary):

- E-Mail: support.de@raymarine.com
- Tel: +49 40 237 808 0

Italy (Raymarine subsidiary):

- E-Mail: support.it@raymarine.com
- Tel: +39 02 9945 1001

Spain (Authorized Raymarine distributor):

- E-Mail: sat@azimut.es
- Tel: +34 96 2965 102

Netherlands (Raymarine subsidiary):

- E-Mail: support.nl@raymarine.com
- Tel: +31 (0)26 3614 905

Sweden (Raymarine subsidiary):

- E-Mail: support.se@raymarine.com
- Tel: +46 (0)317 633 670

Finland (Raymarine subsidiary):

- E-Mail: support.fi@raymarine.com
- Tel: +358 (0)207 619 937

Norway (Raymarine subsidiary):

- E-Mail: support.no@raymarine.com
- Tel: +47 692 64 600

Denmark (Raymarine subsidiary):

- E-Mail: support.dk@raymarine.com
- Tel: +45 437 164 64

Russia (Authorized Raymarine distributor):

- E-Mail: info@mikstmarine.ru
- Tel: +7 495 788 0508

- <http://www.raymarine.co.uk/view/?id=2372>

Technical support forum

You can use the Technical support forum to ask a technical question about a Raymarine product or to find out how other customers are using their Raymarine equipment. The resource is regularly updated with contributions from Raymarine customers and staff:

- <https://raymarine.custhelp.com/app/home>

18.2 Checking the software version

Depending on the instrument display variant follow the steps below to identify the software version of your unit.

During normal operation:

1. **i50 Depth** — Press and hold the *[Depth]* and *[Alarm]* buttons at the same time for approximately 4 seconds.
2. **i50 Speed** — Press and hold the *[Speed]* and *[Trip]* buttons at the same time for approximately 4 seconds.
3. **i50 Tridata** — Press and hold the *[Depth]* and *[Speed]* buttons at the same time for approximately 4 seconds.

The software version will be displayed on-screen.

18.3 Learning resources

Raymarine has produced a range of learning resources to help you get the most out of your products.

Video tutorials

Raymarine official channel on YouTube

- <http://www.youtube.com/user/RaymarineInc>

Training courses

Raymarine regularly runs a range of in-depth training courses to help you make the most of your products. Visit the Training section of the Raymarine website for more information:

[Technical support](#)

CHAPTER 19: TECHNICAL SPECIFICATION

CHAPTER CONTENTS

- 19.1 Physical specification — page 123
- 19.2 Power specification — page 123
- 19.3 Network specification — page 123
- 19.4 Environmental specification — page 123
- 19.5 Display specification — page 123
- 19.6 Conformance specification — page 123

19.1 Physical specification

Specification

Length:	110.00 mm (4.33 in)
Height:	115.00 mm (4.53 in)
Depth:	44.00 mm (1.73 in)

19.2 Power specification

Specification

Nominal supply voltage:	12 V dc
Operating voltage range:	10 V dc to 16 V dc
Power consumption:	<ul style="list-style-type: none">• < 1 W typical (display only)• 2.4 W Maximum (transducer connected)
Current:	<ul style="list-style-type: none">• 45 to 65 mA typical (display only)• 200 ma Maximum (transducer connected)
LEN (Load Equivalency Number):	4

19.3 Network specification

Specification

Network connections:	<ul style="list-style-type: none">• 2x SeaTalk NG connections (complaint with SeaTalk 1).• 2x Transducer connections (i50 Tridata) / 1x Transducer connection (i50 Depth / i50 Speed).
-----------------------------	---

19.4 Environmental specification

Specification

Operating temperature range:	-20°C to +55°C (-4°F to +131°F)
Storage temperature range:	-30°C to +70°C (-22°F to +158°F)

Specification

Relative humidity:	93% Max
Waterproof rating:	IPx6

19.5 Display specification

Specification

Viewing angle:	+70 / +70
-----------------------	-----------

19.6 Conformance specification

Specification

Conformance:	Europe 2004/208/EC
---------------------	--------------------


CHAPTER 20: SPARES AND ACCESSORIES

CHAPTER CONTENTS

- 20.1 Spares — page 125
- 20.2 Accessories — page 125
- 20.3 SeaTalk NG cables and accessories — page 125

20.1 Spares


The following spares are available for your product:



Part	Description
1 R22168	i50 / i60 / i70 front bezel.
2 R22169	i50 / i60 / i70 sun cover.
3 R70131	i50 Depth keypad.
4 R70130	i50 Speed keypad.
5 R70132	i50 Tridata keypad.

20.2 Accessories

The following accessories are available for your product:



Part	Description
1 A80355	i50 / i60 / i70 front bezel black (eS style)
2 A80356	i50 / i60 / i70 front bezel gunmetal (eS style)
3 A80357	i50 / i60 / i70 suncover (for eS style bezel)


20.3 SeaTalk NG cables and accessories

SeaTalk NG cables and accessories for use with compatible products.

SeaTalk NG kits


SeaTalk NG kits enable you to create a simple SeaTalk NG backbone.

Starter kit (part number: T70134) consists of:




- 1 x Spur cable 3 m (9.8 ft) (part number: **A06040**). Used to connect device to the SeaTalk NG backbone.
- 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.
- 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.
- 1 x 5-Way connector (part number: **A06064**). Each connector block allows connection of up to 3 SeaTalk NG devices. Multiple connector blocks can be 'daisy chained' together.

Backbone kit (part number: A25062) consists of:



1. 2 x Backbone cables 5 m (16.4 ft) (part number: **A06036**). Used to create and extend the SeaTalk NG backbone.
2. 1 x Backbone cable 20 m (65.6 ft) (part number: **A06037**). Used to create and extend the SeaTalk NG backbone.
3. 4 x T-piece (part number: **A06028**). Each T-piece allows connection of one SeaTalk NG device. Multiple T-pieces can be 'daisy chained' together.
4. 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.
5. 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.


Evolution-Series autopilot cable kit (part number: R70160) consists of:



1. 1 x Backbone cable 5 m (16.4 ft) (part number: **A06036**). Used to create and extend the SeaTalk NG backbone.

2. 1 x Spur cable 1 m (3.3 ft) (part number: **A06040**). Used to connect device to the SeaTalk NG backbone.
3. 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.
4. 1 x 5-Way connector (part number: **A06064**). Each connector block allows connection of up to 3 SeaTalk NG devices. Multiple connector blocks can be 'daisy chained' together.
5. 2 x T-pieces (part number: **A06028**). Each T-piece allows connection of one SeaTalk NG device. Multiple T-pieces can be 'daisy chained' together.
6. 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.


SeaTalk 1 to SeaTalk NG converter kit (part number: E22158) consists of:



1. 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.
2. 1 x Spur cable 1 m (3.3 ft) (part number: **A06039**). Used to connect a device to the SeaTalk NG backbone.
3. 1 x SeaTalk 1 (3 pin) to SeaTalk NG adapter cable 0.4 m (1.3 ft) (part number: **A22164**). Used to connect SeaTalk 1 devices to the SeaTalk NG backbone via the SeaTalk 1 to SeaTalk NG converter.
4. 1 x SeaTalk 1 to SeaTalk NG converter (part number: **E22158**). Each converter allows connection of one SeaTalk 1 device and up to 2 SeaTalk NG devices.
5. 2 x Spur blanking plugs (part number: **A06032**). Used to cover unused spur connections in 5-way blocks, T-piece connectors and SeaTalk 1 to SeaTalk NG converter.

- 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.


NMEA 0183 VHF 2-wire to SeaTalk NG converter kit (part number: E70196) consists of:



- 1 x Power cable 2 m (6.6 ft) (part number: **A06049**). Used to provide 12 V dc power to the SeaTalk NG backbone.
- 1 x Spur cable 1 m (3.3 ft) (part number: **A06039**). Used to connect a device to the SeaTalk NG backbone.
- 1 x NMEA 0183 VHF stripped-end (2-wire) to SeaTalk NG adapter cable 1 m (3.3 ft) (part number: **A06071**). Used to connect an NMEA 0183 VHF radio to the SeaTalk NG backbone via the NMEA 0183 to SeaTalk NG converter.
- 1 x SeaTalk 1 to SeaTalk NG converter (part number: **E22158**). Each converter allows connection of one SeaTalk 1 device and up to 2 SeaTalk NG devices.
- 2 x Spur blanking plugs (part number: **A06032**). Used to cover unused spur connections in 5-way blocks, T-piece connectors, and the SeaTalk 1 to SeaTalk NG converter.
- 2 x Backbone terminators (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.

SeaTalk NG spur cables

SeaTalk NG spur cables are required to connect devices to the SeaTalk NG backbone.



- SeaTalk NG spur cables:
 - Spur cable 0.4 m (1.3 ft) (part number: **A06038**).
 - Spur cable 1 m (3.3 ft) (part number: **A06039**).
 - Spur cable 3 m (9.8 ft) (part number: **A06040**).
 - Spur cable 5 m (16.4 ft) (part number: **A06041**).
- Elbow (right-angled) to elbow (right-angled) spur cable 0.4 m (1.3 ft) (part number: **A06042**). Used in confined spaces where a straight spur cable will not fit.
- Elbow (right-angled) to straight spur cable 1 m (3.3 ft) (part number: **A06081**). Used in confined spaces where a straight spur cable will not fit.
- SeaTalk NG to stripped-end spur cables (connects compatible products that do not have a SeaTalk NG connector, such as transducer pods):
 - SeaTalk NG to stripped-end spur cable 1 m (3.3 ft) (part number: **A06043**)
 - SeaTalk NG to stripped-end spur cable 3 m (9.8 ft) (part number: **A06044**)
- ACU-Series / SPX-Series autopilot to SeaTalk NG spur cable 0.3 m (1.0 ft) (part number **R12112**). Connects the course computer to the SeaTalk NG backbone. This connection can also be used to provide 12 V dc power to the SeaTalk NG backbone.

SeaTalk NG backbone cables

SeaTalk NG backbone cables are used to create or extend a SeaTalk NG backbone.




1. Backbone cables:

- Backbone cable 0.4 m (1.3 ft) (part number: **A06033**).
 - Backbone cable 1 m (3.3 ft) (part number: **A06034**).
 - Backbone cable 3 m (9.8 ft) (part number: **A06035**).
 - Backbone cable 5 m (16.4 ft) (part number: **A06036**).
 - Backbone cable 9 m (29.5 ft) (part number: **A06068**).
 - Backbone cable 20 m (65.6 ft) (part number: **A06037**).
2. SeaTalk NG to DeviceNet (female) Backbone cable 0.4 m (1.3 ft) (part number: **A80675**)
 3. SeaTalk NG to DeviceNet (male) Backbone cable 0.4 m (1.3 ft) (part number: **A80674**)

SeaTalk NG power cables


SeaTalk NG power cables are used to provide the SeaTalk NG backbone with a single 12 V dc power source. The power connection must include a 5 amp inline fuse (not supplied).



1. Power cable (straight) 2 m (6.6 ft) (part number: **A06049**).
2. Elbow (right-angled) power cable 2 m (6.6 ft) (part number: **A06070**).

SeaTalk NG connectors


SeaTalk NG connectors are used to connect SeaTalk NG devices to the SeaTalk NG backbone and to create and extend the backbone.



1. 5-Way connector (part number: **A06064**). Each connector block allows connection of up to 3 SeaTalk NG devices. Multiple connector blocks can be 'daisy chained' together.
2. T-piece (part number: **A06028**). Each T-piece allows connection of one SeaTalk NG device. Multiple T-pieces can be 'daisy chained' together.
3. Backbone extender (part number: **A06030**). Used to connect 2 backbone cables together.
4. Inline terminator (part number: **A80001**). Used to connect a spur cable and SeaTalk NG device at the end of a backbone instead of a backbone terminator.
5. Backbone terminator (part number: **A06031**). Terminators must be fitted to both ends of the SeaTalk NG backbone.
6. Spur blanking plug (part number: **A06032**). Used to cover unused spur connections in 5-Way blocks, T-piece connectors, or the SeaTalk 1 to SeaTalk NG converter.
7. Elbow (right-angled) spur connector (part number: **A06077**). Used in confined spaces where a straight spur cable will not fit.

SeaTalk NG adaptors and adaptor cables

SeaTalk NG adaptor cables are used to connect devices designed for different CAN Bus backbones (e.g.: SeaTalk 1 or DeviceNet) to the SeaTalk NG backbone.



1. SeaTalk 1 (3 pin) to SeaTalk NG converter cable 1 m (3.3 ft) (part number: **A22164 / A06073**). Can be used to connect a SeaTalk 1 device to a SeaTalk NG backbone via the SeaTalk 1 to SeaTalk NG converter, or to connect a SeaTalk NG product directly to a SeaTalk 1 network.
2. SeaTalk 1 (3 pin) to SeaTalk NG adaptor cable 0.4 m (1.3 ft) (part number: **A06047**). Can be used to connect a SeaTalk 1 device to a SeaTalk NG backbone via the SeaTalk 1 to SeaTalk NG converter, or to connect a SeaTalk NG product directly to a SeaTalk 1 network.
3. SeaTalk 2 (5 pin) to SeaTalk NG adaptor cable 0.4 m (1.3 ft) (part number: **A06048**). Used to connect SeaTalk 2 devices or networks to a SeaTalk NG backbone.
4. SeaTalk NG to DeviceNet (female) adaptor cables connect NMEA 2000 devices that use a DeviceNet connector to the SeaTalk NG backbone, or connects SeaTalk NG devices to an NMEA 2000 network. The following cables are available:
 - SeaTalk NG to DeviceNet (female) adaptor cable 0.4 m (1.3 ft) (part number: **A06045**).
 - SeaTalk NG to DeviceNet (female) adaptor cable 1 m (3.3 ft) (part number: **A06075**).
5. SeaTalk NG to DeviceNet (male) adaptor cables. Connect NMEA 2000 devices that use a DeviceNet connector to the SeaTalk NG backbone, or connect SeaTalk NG devices to an NMEA 2000 network. The following cables are available:

- SeaTalk NG to DeviceNet (male) adaptor cable 0.1 m (0.33 ft) (part number: **A06078**).
 - SeaTalk NG to DeviceNet (male) adaptor cable 0.4 m (1.3 ft) (part number: **A06074**).
 - SeaTalk NG to DeviceNet (male) adaptor cable 1 m (3.3 ft) (part number: **A06076**).
 - SeaTalk NG to DeviceNet (male) adaptor cable 1.5 m (4.92 ft) (part number: **A06046**).
6. NMEA 0183 stripped-end (2-wire) to SeaTalk NG adapter cable 1 m (3.3 ft) (part number: **A06071**). Used to connect an NMEA 0183 VHF radio to the SeaTalk NG backbone via the NMEA 0183 to SeaTalk NG converter.
 7. SeaTalk NG (male) to DeviceNet (female) adaptor (**A06082***).
 8. SeaTalk NG (female) to DeviceNet (male) adaptor (**A06083***).
 9. SeaTalk NG (male) to DeviceNet (female) elbow (right-angled) adaptor (**A06084***).
 10. DeviceNet (female) to stripped-end adaptor cable (0.4 m (1.3 ft)) (part number: **E05026**).
 11. DeviceNet (male) to stripped-end adaptor cable (0.4 m (1.3 ft)) (part number: **E05027**).

Important:

* Do NOT connect the A06082, A06083, or A06084 adaptors directly to a backbone. Only connect as part of a **spur** connection between backbone and device.

Appendix A NMEA 2000 PGNs

The i50 instrument range supports the following NMEA 2000 Parameter Group Numbers (PGNs).

i50 Depth:

PG name	PGN	Transmit	Receive
ISO Acknowledgement	59392	●	
ISO Request	59904		●
ISO Address claim	60928	●	●
ISO Commanded address	65240		●
NMEA Request group function	126208		●
NMEA Command group function	126208		●
NMEA Acknowledge group function	126208	●	
PGN list — Transmit PGN's group function	126464	●	
PGN list — Received PGN's group function	126464	●	
Product information	126996	●	●
Water depth	128267	●	●

i50 Speed:

PG name	PGN	Transmit	Receive
ISO Acknowledgement	59392	●	
ISO Request	59904		●
ISO Address claim	60928	●	●
ISO Commanded address	65240		●
NMEA Request group function	126208		●

PG name	PGN	Transmit	Receive
NMEA Command group function	126208	●	●
NMEA Acknowledge group function	126208	●	●
PGN list — Transmit PGN's group function	126464	●	
PGN list — Received PGN's group function	126464	●	
Product information	126996	●	●
Speed	128259	●	●
Distance log	128275	●	●
COG & SOG rapid update	129026		●
GNSS Position data	129029		●
Wind data	130306		●
Environmental parameters	130310	●	●
Environmental parameters	130311		●
Temperature	130312	●	●

i50 Tridata:

PG name	PGN	Transmit	Receive
ISO Acknowledgement	59392	●	
ISO Request	59904		●
ISO Address claim	60928	●	●
ISO Commanded address	65240		●
NMEA Request group function	126208		●
NMEA Command group function	126208	●	●
NMEA Acknowledge group function	126208	●	●

PG name	PGN	Transmit	Receive
PGN list — Transmit PGN's group function	126464	●	
PGN list — Received PGN's group function	126464	●	
Product information	126996	●	●
Speed	128259	●	●
Water depth	128267	●	
Distance log	128275	●	●
COG & SOG rapid update	129026		●
GNSS Position data	129029		●
Wind data	130306		●
Environmental parameters	130310	●	●
Environmental parameters	130311		●
Temperature	130312	●	●

Appendix B Software release history

The list below is a cumulative list of the new features introduced in subsequent releases of the i50 software, since the initial release (v1.06).

This list includes *new features* only. It does NOT include software maintenance items, such as bug fixes or performance improvements.

i50 v1.06:

(Software release date: *October 2012*)

- Initial public release.

Index

A

Accessories	
SeaTalk NG adaptor cables	128
SeaTalk NG backbone cables	127
SeaTalk NG cables	125
SeaTalk NG connectors	128
SeaTalk NG kits	125
SeaTalk NG Power cables	128
SeaTalk NG spur cables	127
Applicable documents.....	15

B

Backbone length,	
SeaTalk NG.....	48
Box contents	22

C

Cable	
Bend radius.....	33
Protection	33
Routing	33
Security.....	33
Strain relief.....	33
Calibration	
Depth.....	65, 94
Speed	78, 98
CAN bus	20
Cleaning	11, 114
Screen.....	114
Compass safe distance	12, 27
Connecting cables.....	34
Connections	
Bare-ended wires	34
Battery	50, 59
Distribution panel.....	49, 58
Power.....	46, 48, 51
Power connections	

Power distribution	49
SeaTalk NG.....	42
Wire	34
Contact details.....	120

D

Depth calibration	65, 94
Depth offset.....	65, 94
DeviceNet.....	20
Dimensions.....	24
Distribution panel connection	49
Documentation	15

E

Electromagnetic Compatibility.....	11, 26
EMC, <i>See</i> Electromagnetic Compatibility	

F

Fuse rating.....	57
Fuse requirement	22, 46, 54, 57

I

Inline fuse	22, 46, 54, 57
Installation	
Best practice	59
Mounting.....	29
Interference	12, 27
<i>See also</i> Compass safe distance	
iTC-5 connection	39

L

Load equivalency number	48
Location requirements	
General	26
Viewing angle	27

M

Maintenance.....	10, 114
Mounting	29–30
Mounting templates.....	15

N

Network length, SeaTalk NG.....	48
NMEA 2000.....	20
LEN	47

P

Parts supplied.....	22
Power	
Battery connection.....	50, 59
Cable extension.....	60
Connection to battery.....	59
Connection to distribution panel	58
Distribution	57
Distribution panel.....	49, 58
Fuses	22, 46, 54, 57
Grounding.....	59
Sharing a breaker	49, 58
Power cable extension	50, 60
Power connection point	48
Power off	63, 75, 92
Power on	63, 75, 92
Power troubleshooting.....	117
Printed manual	15
Product documentation.....	15
Product loading.....	47
Product recycling (WEEE)	13
Product support.....	120
Protocols	
DeviceNet.....	20
NMEA 2000.....	20
SeaTalk 1.....	20
SeaTalk NG.....	20

R

Routine checks.....	114
---------------------	-----

S

SeaTalk 1	20
SeaTalk NG	20, 42, 49
Adaptor cables	128
Backbone cables	127
Connectors	128
Kits.....	125
LEN	47
Load equivalency number	47
Power.....	46, 48, 51
Power cables	47, 128
Spur cables.....	127
System loading	48
SeaTalk NG cables	125
Service Center.....	120
Servicing.....	10, 114
Software version.....	16
Spade terminals.....	35
Spares	125
Specification	
Dimensions	24
Speed calibration	
Measured mile	78, 98
Mile markers	78, 98
Support forum	121
Suppression ferrites	12, 33
<i>See also</i> EMC	
Switching on.....	63, 75, 92

T

Technical specification.....	122
Conformance specification.....	123
Display specification.....	123
Environmental specification.....	123
Network specification	123
Power specification.....	123
Technical support.....	120–121

Thermal breaker rating	57
Tools required	30
Training courses	121
Transducer pod	40
Troubleshooting	116
Power.....	117

V

Ventilation	26
-------------------	----

W

Warranty	12, 120
WEEE Directive	13
What's in the box.....	22



Raymarine (UK / EU)

Marine House, Cartwright Drive,
Fareham, Hampshire.
PO15 5RJ.
United Kingdom.

Tel: (+44) (0)1329 246 700

www.raymarine.co.uk

Raymarine (US)

110 Lowell Road,
Hudson, NH 03051.
United States of America.

Tel: (+1) 603-324-7900

www.raymarine.com



Raymarine®